

**Controller Integrated 2-Phase Closed-Loop
Stepper Motor System**

AiC-D Series

Library Manual

CE



AiC-D Series

Preface

Thank you for purchasing Autonics product.

Please familiarize yourself with the information contained in the Safety Precautions section before using this product.

This user manual contains information about the product and its proper use, and should be kept in a place where it will be easy to access.

User Manual Guide

Please familiarize yourself with the information in this manual before using the product.

- This manual provides detailed information on the product's features. It does not offer any guarantee concerning matters beyond the scope of this manual.
- This manual may not be edited or reproduced in either part or whole without permission.
- A user manual is not provided as part of the product package. Visit our web site (www.autonics.com) to download a copy.
- The manual's content may vary depending on changes to the product's software and other unforeseen developments within Autonics, and is subject to change without prior notice. Upgrade notice is provided through out homepage.
- We contrived to describe this manual more easily and correctly. However, if there are any corrections or questions, please notify us these on our homepage.

User Manual Symbols

Symbol	Description
 Note	Supplementary information for a particular feature.
 Warning	Failure to follow instructions can result in serious injury or death.
 Caution	Failure to follow instructions can lead to a minor injury or product damage.
 Ex.	An example of the concerned feature's use.
※1	Annotation mark.

Safety Precautions

- Following these safety precautions will ensure the safe and proper use of the product and help prevent accidents, as well as minimizing possible hazards.
- Safety precautions are categorized as Warnings and Cautions, as defined below:

	Warning	Warning	Failure to follow these instructions may result in serious injury or death.
---	----------------	----------------	---

	Caution	Caution	Failure to follow these instructions may result in personal injury or product damage.
---	----------------	----------------	---



Warning

- Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.) Failure to follow this instruction may result in fire, personal injury, or economic loss.
- Do not connect, repair, or inspect the unit while connected to a power source. Failure to follow this instruction may result in fire.
- Install the unit after considering counter plan against power failure. Failure to follow this instruction may result in personal injury, or economic loss.
- Check 'Connections' before wiring. Failure to follow this instruction may result in fire.
- Do not disassemble or modify the unit. Failure to follow this instruction may result in fire.
- Install the driver in the grounded housing or ground it directly. Failure to follow this instruction may result in electronic shock, personal injury.
- Do not touch the unit during or after operation for a while. Failure to follow this instruction may result in burn due to high temperature of the surface.
- Emergency stop directly when error occurs. Failure to follow this instruction may result in fire, or personal injury.



Caution

- When connecting the power input, use AWG 18(0.75mm²) cable or over.
- Brake is non-polar. When connecting the brake, use AWG 24 (0.2mm²) cable or over. Failure to follow this instruction may result in fire or malfunction due to contact failure.
- To use the motor safely, do not apply external force to the motor.
- It is recommended to use STOPPER for the vertical load.
- Install over-current prevention device (e.g. the current breaker, etc) to connect the driver with power. Failure to follow this instruction may result in fire.
- Check the control input signal before supplying power to the driver. Failure to follow this instruction may result in personal injury or product damage by unexpected signal.
- Install a safety device to maintain the vertical position after turn off the power of this driver. Failure to follow this instruction may result in personal injury or product damage by releasing holding torque of the motor.

- Use the unit within the rated specifications.
Failure to follow this instruction may result in fire or product damage.
- Use dry cloth to clean the unit, and do not use water or organic solvent.
Failure to follow this instruction may result in fire.
- Do not use the unit in the place where flammable/explosive/corrosive gas, humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present.
Failure to follow this instruction may result in fire or explosion.
- The driver may overheat depending on the environment. Install the unit in the well ventilated place and forced cooling with a cooling fan.
Failure to follow this instruction may result in product damage and degradation by heat.
- Keep metal chip, dust, and wire residue from flowing into the unit.
Failure to follow this instruction may result in fire or product damage.
- Use the designated motor only.
Failure to follow this instruction may result in fire or product damage.

The specifications and dimensions of this manual are subject to change and some models may be discontinued without notice.

Cautions during Use

- Follow instructions in 'Cautions during Use'.
Otherwise, it may cause unexpected accidents.
- 24VDC power supply should be insulated and limited voltage/current or Class 2, SELV power supply device.
- Re-supply power after min. 1 sec from disconnected power.
- In case communication is unstable due to the noise generated by supplied power or peripheral device, use ferrite core at communication line.
- It is recommended to use 485 converter with the separate power.
(Autonics product, SCM-38I, recommended)
- The thickness of cable should be same or thicker than the motor cable's when extending the motor cable.
- Keep the distance between power cable and signal cable more than 10cm.
- Motor vibration and noise can occur in specific frequency period
 - ① Change motor installation method or attach the damper.
 - ② Use the unit out of the dedicated frequency range when vibration and noise occurs due to changing motor RUN speed.
- For using motor, it is recommended to maintenance and inspection regularly.
 - ① Unwinding bolts and connection parts for the unit installation and load connection
 - ② Strange sound from ball bearing of the unit
 - ③ Damage and stress of lead cable of the unit
 - ④ Connection error with motor
 - ⑤ Inconsistency between the axis of motor output and the center, concentric (eccentric, declination) of the load, etc.
- This product does not prepare protection function for a motor.
- This unit may be used in the following environments.
 - ① Indoors (in the environment condition rated in 'Specifications')
 - ② Altitude max. 2,000m
 - ③ Pollution degree 2
 - ④ Installation category II

Table of Contents

Preface	iii
User Manual Guide	iv
User Manual Symbols	v
Safety Precautions	vi
Cautions during Use	viii
Table of Contents	ix
1 Reset	15
1.1 autaic_Open.....	15
1.2 autaic_SetBaudrate	17
1.3 autaic_SetParity.....	18
1.4 autaic_SetStopbit.....	19
1.5 autaic_SetResponseTime.....	20
1.6 autaic_SetReset	21
1.7 autaic_SetALMReset	22
1.8 autaic_ClrActualPos	23
1.9 autaic_ClrLogicalPos	24
2 Stop, End	25
2.1 autaic_Close	25
2.2 autaic_InstantStop	26
2.3 autaic_SlowStop	27
2.4 autaic_SetEmgStop	28
3 Parameter	29
3.1 General settings.....	29
3.1.1 autaic_SetLmtStopMod	29
3.1.2 autaic_SetSCurve	30
3.1.3 autaic_SetInputFilter	31
3.1.4 autaic_SetSofLmtEnable.....	32
3.1.5 autaic_SetPowHomStart	33
3.1.6 autaic_SetPowPgmStart	34
3.1.7 autaic_SetStopCurrentFix	35
3.1.8 autaic_SetInputStart.....	36
3.1.9 autaic_SetInputStep0 / autaic_SetInputStep1	37
3.1.10 autaic_SetInputStep2 / autaic_SetInputStep3	38
3.1.11 autaic_SetInputStep4 / autaic_SetInputStep5	39
3.1.12 autaic_SetInputMODE0 / autaic_SetInputMODE1	40
3.1.13 autaic_SetInputPAUSE	41
3.1.14 autaic_SetInputSTOP	42
3.1.15 autaic_SetInputEMG	43
3.1.16 autaic_SetInputHOME	44
3.1.17 autaic_SetInputALMReset	45
3.1.18 autaic_SetInputServoOn	46
3.1.19 autaic_SetLmtActLev	47

3.1.20	autaic_SetInputLev0 to autaic_SetInputLev8	48
3.1.21	autaic_SetSDMode	49
3.1.22	autaic_SetControlMode	50
3.1.23	autaic_SetMotorDir	51
3.1.24	autaic_SetOutputMode	52
3.1.25	autaic_GetLmtStopMod	53
3.1.26	autaic_GetSCurve	54
3.1.27	autaic_GetInputFilter	55
3.1.28	autaic_GetSofLmtEnable	56
3.1.29	autaic_GetPowHomStart	57
3.1.30	autaic_GetPowPgmStart	58
3.1.31	autaic_GetStopCurrentFix	59
3.1.32	autaic_GetInputStart	60
3.1.33	autaic_GetInputStep0 / autaic_GetInputStep1	61
3.1.34	autaic_GetInputStep2 / autaic_GetInputStep3	62
3.1.35	autaic_GetInputStep4 / autaic_GetInputStep5	63
3.1.36	autaic_GetInputMODE0 / autaic_GetInputMODE1	64
3.1.37	autaic_GetInputPAUSE	65
3.1.38	autaic_GetInputSTOP	66
3.1.39	autaic_GetInputEMG	67
3.1.40	autaic_GetInputHOME	68
3.1.41	autaic_GetInputALMReset	69
3.1.42	autaic_GetInputServoOn	70
3.1.43	autaic_GetLmtActLev	71
3.1.44	autaic_GetInputLev0 to autaic_GetInputLev8	72
3.1.45	autaic_GetSDMode	73
3.1.46	autaic_GetControlMode	74
3.1.47	autaic_GetMotorDir	75
3.1.48	autaic_GetOutputMode	76
3.1.49	autaic_GetBitSetGroup	77
3.2	Operation setting	78
3.2.1	autaic_SetInitStartSpd	78
3.2.2	autaic_SetInitMaxSpd	79
3.2.3	autaic_SetInitAccTime	80
3.2.4	autaic_SetInitDecTime	81
3.2.5	autaic_SetInitPosition	82
3.2.6	autaic_SetInitPgmStep	83
3.2.7	autaic_SetInitDrvSet	84
3.2.8	autaic_SetStrSpdChg	85
3.2.9	autaic_SetMaxSpdChg	86
3.2.10	autaic_GetInitStartSpd	87
3.2.11	autaic_GetInitMaxSpd	88
3.2.12	autaic_GetInitAccTime	89
3.2.13	autaic_GetInitDecTime	90
3.2.14	autaic_GetInitPosition	91
3.2.15	autaic_GetInitPgmStep	92
3.2.16	autaic_SetStartDrvSpd1 to autaic_SetStartDrvSpd5	93
3.2.17	autaic_SetMaxDrvSpd1 to autaic_SetMaxDrvSpd5	94
3.2.18	autaic_SetDelayTime1 to autaic_SetDelayTime5	95
3.2.19	autaic_SetAccTime1 to autaic_SetAccTime5	96
3.2.20	autaic_SetDecTime1 to autaic_SetDecTime5	97
3.2.21	autaic_SetSCurvTime	98

3.2.22	autaic_SetSoftLmtPlus	99
3.2.23	autaic_SetSoftLmtMinus	100
3.2.24	autaic_SetONTime1 to autaic_SetONTime5	101
3.2.25	autaic_SetCompareMode1 / autaic_SetCompareMode2	102
3.2.26	autaic_SetCompare1PulseWidth/autaic_SetCompare2PulseWidth	103
3.2.27	autaic_SetCompare1Period / autaic_SetCompare2Period	104
3.2.28	autaic_SetCompare1Position / autaic_SetCompare2Position	105
3.2.29	autaic_SetResolution	106
3.2.30	autaic_SetMotorACtResp	108
3.2.31	autaic_SetStopCurrent	110
3.2.32	autaic_GetStartDrvSpd1 to autaic_GetStartDrvSpd5	111
3.2.33	autaic_GetMaxDrvSpd1 to autaic_GetMaxDrvSpd5	112
3.2.34	autaic_GetDelayTime1 to autaic_GetDelayTime5	113
3.2.35	autaic_GetAccTime1 to autaic_GetAccTime5	114
3.2.36	autaic_GetDecTime1 to autaic_GetDecTime5	115
3.2.37	autaic_GetSCurvTime	116
3.2.38	autaic_GetSofLmtPlus	117
3.2.39	autaic_GetSofLmtMinus	118
3.2.40	autaic_GetONTime1 to autaic_GetONTime5	119
3.2.41	autaic_GetCompareMode1 / autaic_GetCompareMode2	120
3.2.42	autaic_GetCompare1PulseWidth/autaic_GetCompare2PulseWidth	121
3.2.43	autaic_GetCompare1Period / autaic_GetCompare2Period	122
3.2.44	autaic_GetCompare1Position / autaic_GetCompare2Position	123
3.2.45	autaic_GetResolution	124
3.2.46	autaic_GetMotorActResp	125
3.2.47	autaic_GetStopCurrent	126
3.2.48	autaic_GetActGroup	127
3.3	Home search setting	128
3.3.1	autaic_SetInitHomeRunMode	128
3.3.2	autaic_GetInitHomeRunMode	129
3.3.3	autaic_SetHomeMaxSpd	130
3.3.4	autaic_SetHomeStartSpd	131
3.3.5	autaic_SetHomeAccTime	132
3.3.6	autaic_SetHomeDecTime	133
3.3.7	autaic_SetHomeDir	134
3.3.8	autaic_SetHomeOffset	135
3.3.9	autaic_SetHomePos	136
3.3.10	autaic_SetORGSigLev	137
3.3.11	autaic_SetHomeTorque	138
3.3.12	autaic_GetHomeMaxSpd	139
3.3.13	autaic_GetHomeStartSpd	140
3.3.14	autaic_GetHomeAccTime	141
3.3.15	autaic_GetHomeDecTime	142
3.3.16	autaic_GetHomeDir	143
3.3.17	autaic_GetHomeOffset	144
3.3.18	autaic_GetHomePos	145
3.3.19	autaic_GetORGSigLev	146
3.3.20	autaic_GetHomeTorque	147
3.3.21	autaic_GetHomeGroup	148
4	I/O Control	149
4.1	autaic_SetUserOut0 to autaic_SetUserOut9	149

4.2	autaic_GetUserOut0 to autaic_GetUserOut9.....	150
4.3	autaic_GetUserOutGroup.....	151
4.4	autaic_exGetDrvStart	152
4.5	autaic_exGetSTEPsL0 to autaic_exGetSTEPsL5	153
4.6	autaic_exGetMODE0 / autaic_exGetMODE1	154
4.7	autaic_exGetPause	155
4.8	autaic_exGetSlowStop	156
4.9	autaic_exGetEMGStop.....	157
4.10	autaic_exGetHomeRun	158
4.11	autaic_exGetORG	159
4.12	autaic_exGetALMReset.....	160
4.13	autaic_exGetServoOn	161
4.14	autaic_exGetLimitPlus.....	162
4.15	autaic_exGetLimitMinus	163
4.16	autaic_exGetUserInput 0 to autaic_exGetUserInput8	164
4.17	autaic_exGetSDmode	165
4.18	autaic_exGetALMSignal	166
4.19	autaic_exGetInposition	167
4.20	autaic_exGetCompare1 / autaic_exGetCompare2	168
4.21	autaic_GetExInputGroup	169
5	Movement control	171
5.1	autaic_ContPulseCW	171
5.2	autaic_ContPulseCCW	172
5.3	autaic_ABSMove	173
5.4	autaic_INCMove	174
5.5	autaic_HomeModeRun.....	175
6	Program Control.....	177
6.1	autaic_IndexModeRun.....	177
6.2	autaic_PgmModeRun	178
6.3	autaic_PgmPause.....	179
6.4	autaic_PgmStop	180
6.5	autaic_PgmABS.....	181
6.6	aic_PgmINC.....	183
6.7	autaic_PgmHOM	185
6.8	autaic_PgmICJ	186
6.9	autaic_PgmIRD.....	187
6.10	autaic_PgmOPC	188
6.11	autaic_PgmOPT	189
6.12	autaic_PgmJMP.....	190
6.13	autaic_PgmREP	191
6.14	autaic_PgmRPE	192
6.15	autaic_PgmEND	193

6.16	autaic_PgmPOS	194
6.17	autaic_PgmTIM.....	195
6.18	autaic_PgmCMP.....	196
6.19	autaic_PgmDelAll	198
6.20	autaic_PgmDelStep	199
6.21	autaic_GetPgmData	200
7	Monitoring Data.....	201
7.1	autaic_GetDriverMode.....	201
7.2	autaic_GetLogicalPos.....	202
7.3	autaic_GetActualPos	203
7.4	autaic_GetLogicalDrvSpd	204
7.5	autaic_GetActualDrvSpd	205
7.6	autaic_GetMotorRPM	206
7.7	autaic_GetCurPgmNo.....	207
7.8	autaic_GetErrorSt.....	208
7.9	autaic_GetParallell01.....	209
7.10	autaic_GetParallell02.....	210
7.11	autaic_GetParallell03.....	211
7.12	autaic_MonitorData.....	212
8	Product Information.....	213
8.1	autaic_GetSofVer.....	213
8.2	autaic_GetModName	214
8.3	autaic_GetCoilStatusStartAddress	215
8.4	autaic_GetCoilStatusQuantity	216
8.5	autaic_GetInputStatusStartAddress	217
8.6	autaic_GetInputStatusQuantity.....	218
8.7	autaic_GetHoldingRegisterStartAddress.....	219
8.8	autaic_GetHoldingRegisterQuantity	220
8.9	autaic_GetInputRegisterStartAddress.....	221
8.10	autaic_GetInputRegisterQuantity	222
9	Example of Library Usage	223
9.1	Reset.....	223
9.2	Stop, End	226
9.3	Parameter setting	227
9.4	Movement control	229
9.5	Program mode	230
9.6	Monitoring data	234
9.7	Product information.....	237

1 Reset

1.1 *autaic_Open*

This function, *autaic_Open*, is for connecting to communication.

(1) Function

```
int autaic_Open(
    int PortNum,
    int BaudRate,
    int Parity,
    int Stopbit
);
```

(2) Parameter

- PortNum: Enter serial port number to be connected.
- BaudRate: Enter baudrate of serial port.

Type	Input	Description	Constant value
AIC_BAUDRATE	AIC_BAUD_9600	9,600bps	9600
	AIC_BAUD_19200	19,200bps	19200
	AIC_BAUD_38400	38,400bps	38400
	AIC_BAUD_57600	57,600bps	57600
	AIC_BAUD_115200	115,200bps	115200

- Parity: Enter parity bit.

Type	Input	Description	Constant value
AIC_PARITY	AIC_PARITY_NONE	None	0
	AIC_PARITY_EVEN	Even	1
	AiC_PARITY_ODD	Odd	2

- Stopbit: Enter stop bit.

Type	Input	Description	Constant value
AIC_STOPBIT	AIC_STOPBIT_1	STOP BIT 1	0
	AIC_STOPBIT_2	STOP BIT 2	1

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

1.2 **autaic_SetBaudrate**

This function, autaic_SetBaudrate, is for changing baud rate.

(1) **Function**

```
int autaic_SetBaudrate(
    int PortNum,
    char nNodeId,
    int iBaudrate
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

1.3 **autaic_SetParity**

This function, autaic_SetParity, is for changing parity bit.

(1) **Function**

```
int autaic_SetParity(
    int PortNum,
    char nNodeId,
    int iParity
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.
- iParity: Enter parity bit. (0: None, 1: Even, 2: Odd)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

1.4 **autaic_SetStopbit**

This function, autaic_SetStopbit, is for changing stop bit.

(1) **Function**

```
int autaic_SetBaudrate(
    int PortNum,
    char nNodeId,
    int iStopbit
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
 - Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.
- iStopbit: Enter stop bit to be changed. (0: 1, 1: 2)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

1.5 **autaic_SetResponseTime**

This function, autaic_SetResponseTime, is for setting response time.

(1) **Function**

```
int autaic_SetResponseTime(
    int PortNum,
    char nNodeId,
    int iTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.
- iTime: Select the response wait time (1 to 99) of the drive.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

1.6 **autaic_SetReset**

This function, autaic_SetReset is for setting reset.

(1) **Function**

```
int autaic_SetReset(
    int PortNum,
    char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

1.7 **autaic_SetALMReset**

This function, autaic_SetALMReset, is for resetting alarms.

(1) **Function**

```
int autaic_SetALMReset(
    int PortNum,
    char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId

Select the node ID. The range of node ID is 0 to 31.

When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.

Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

1.8 **autaic_ClrActualPos**

This function, autaic_ClrActualPos, is for resetting actual coordinate value (actual motor position coordinate) as "0".

(1) **Function**

```
int autaic_ClrActualPos(
    int PortNum,
    char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

1.9 **autaic_ClrLogicalPos**

This function, autaic_ClrActualPos is for resetting command position coordinate value (motor position coordinate by command) as “0”.

(1) **Function**

```
int autaic_ClrLogicalPos(
    int PortNum,
    char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId

Select the node ID. The range of node ID is 0 to 31.

When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.

Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

2 Stop, End

2.1 *autaic_Close*

This function, *autaic_Close*, is for disconnecting communication.

(1) Function

```
int autaic_Close(
    int PortNum
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

2.2 **autaic_InstantStop**

This function, autaic_InstantStop, is for instant stopping without acceleration/deceleration.

(1) **Function**

```
int autaic_InstantStop(
    int PortNum,
    char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId

Select the node ID. The range of node ID is 0 to 31.

When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.

Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

2.3 **autaic_SlowStop**

This function, autaic_SlowStop, is for decelerating and stopping according to the set deceleration time.

(1) **Function**

```
int autaic_SlowStop(
int PortNum,
char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

2.4 **autaic_SetEmgStop**

This function, autaic_SetEmgStop, is for emergency stopping and generating emergency stop alarm.

(1) **Function**

```
int autaic_SetEmgStop(
    int PortNum,
    char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId

Select the node ID. The range of node ID is 0 to 31.

When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.

Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3 Parameter

3.1 General settings

3.1.1 *autaic_SetLmtStopMod*

This function, *autaic_SetLmtStopMod*, is for setting limit stop mode.

(1) Function

```
int autaic_SetLmtStopMod(
    int PortNum,
    char nNodeId,
    BOOL bInstant
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
- bInstant: Select stop method. (0: instant stop, 1: deceleration stop)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.2 **autaic_SetSCurve**

This function, autaic_SetSCurve, is for setting to use S Curve(S curve acceleration/deceleration) for AiC drive.

(1) **Function**

```
int autaic_SetSCurve (
    int PortNum,
    char nNodeId,
    BOOL bEnable
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bEnable: Select enable/disable of S Curve(S curve acceleration/deceleration). (0: Disable, 1: Enable)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.3 **autaic_SetInputFilter**

This function, autaic_SetInputFilter, is for setting software filter of I/O except “IN7 to IN8”, “±Limit”, “ORG”, “SD”.

(1) **Function**

```
int autaic_SetInputFilter (
    int PortNum,
    char nNodeId,
    BOOL bFilter
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bFilter: Select software filter value. (0: 10ms, 1: 1.5ms)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.4 **autaic_SetSofLmtEnable**

This function, `autaic_SetSofLmtEnable`, is for setting enable/disable of Software Limit (software limit).

(1) **Function**

```
int autaic_SetSofLmtEnable (
    int PortNum,
    char nNodeId,
    BOOL bEnable
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- bEnable: Select enable/disable of Software Limit (software limit). (0: Disable, 1: Enable)

(3) **Return value**

Type	Definition	Return value	Description
Normal	<code>AIC_OK</code>	0	The function executes the command normally.
Input error	<code>AIC_INVALID_COMMAND</code>	1	Invalid command is entered.
	<code>AIC_INVALID_ADDRESS</code>	2	Invalid address is entered.
	<code>AIC_INVALID_ADDRESS_COUNT</code>	3	Invalid address counter is entered.
	<code>AIC_INVALID_PROCESS</code>	4	Invalid process
	<code>AIC_INVALID_PORT</code>	5	Entered port is not available or invalid port number is entered.
	<code>AIC_INVALID_BAUDRATE</code>	6	Invalid baudrate is entered.
	<code>AIC_INVALID_PARITYBIT</code>	7	Invalid parity bit is entered.
	<code>AIC_INVALID_STOPBIT</code>	8	Invalid stop bit is entered.
	<code>AIC_INVALID_NODE</code>	9	Invalid node number
	<code>AIC_INVALID_DATA</code>	10	Invalid data
	<code>AIC_INVALID_COMMUNICATION</code>	11	Communication error
	<code>AIC_CRC_ERROR</code>	12	CRC error
	<code>AIC_NO_RESPONSE_MESSAGE</code>	13	No response

3.1.5 **autaic_SetPowHomStart**

This function, autaic_SetPowHomStart, is for home search automatically when power is ON.

(1) **Function**

```
int autaic_SetPowHomStart (
    int PortNum,
    char nNodeId,
    BOOL bEnable
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bEnable: Select enable/disable of the command for home search automatically when power is ON.
(0: Disable, 1: Enable)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.6 **autaic_SetPowPgmStart**

This function, autaic_SetPowPgmStart, is for starting by the registered program when power is ON.

(1) **Function**

```
int autaic_SetPowPgmStart (
    int PortNum,
    char nNodeId,
    BOOL bEnable
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bEnable: Select enable/disable of the command for starting program automatically when power is ON. (0: Disable, 1: Enable)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.7 **autaic_SetStopCurrentFix**

This function, autaic_SetStopCurrentFix, is for setting fixed/not fixed stop current.

(1) **Function**

```
int autaic_SetStopCurrentFix (
    int PortNum,
    char nNodeId,
    BOOL bEnable
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bEnable: Select fix/not fix of stop current. (0: Not fix, 1: Fix)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.8 **autaic_SetInputStart**

This function, autaic_SetInputStart, is for setting start signal to drive the set drive mode (index/program mode) of AiC.

(1) **Function**

```
int autaic_SetInputStart (
    int PortNum,
    char nNodeId,
    BOOL bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select start signal level of index/program mode. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.9 **autaic_SetInputStep0 / autaic_SetInputStep1**

This function, autaic_SetInputStep0, is for setting Step0/+Run/+Jog (designate step 0/+continuous/+jog) input signal.

This function, autaic_SetInputStep1, is for setting Step1/-Run/-Jog(designate step 1/-continuous/-jog) input signal.

(1) **Function: autaic_SetInputStep0**

```
int autaic_SetInputStep0 (
    int PortNum,
    char nNodeId,
    BOOL bActLev
);
```

(2) **Function: autaic_SetInputStep1**

```
int autaic_SetInputStep1 (
    int PortNum,
    char nNodeId,
    BOOL bActLev
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select each logic level of Step0, 1/±Run/±Jog(designate step 0, 1/±continuous/±jog)
(0: Low, 1: High)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.10 **autaic_SetInputStep2 / autaic_SetInputStep3**

This function, autaic_SetInputStep2, is for setting Step2/SSP0(designate step 2/start drive speed 0) input signal.

This function, autaic_SetInputStep3, is for setting Step3/SSP1(designate step 3/start drive speed 1) input signal.

(1) **Function: autaic_SetInputStep2**

```
int autaic_SetInputStep2 (
    int PortNum,
    char nNodeId,
    BOOL bActLev
);
```

(2) **Function: autaic_SetInputStep3**

```
int autaic_SetInputStep3 (
    int PortNum,
    char nNodeId,
    BOOL bActLev
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select each logic level of Step2, 3/SSP0, 1(designate step 2, 3/start drive speed 0, 1).
(0: Low, 1: High)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.11 **autaic_SetInputStep4 / autaic_SetInputStep5**

This function, autaic_SetInputStep4, is for setting Step4/MSP0(designate step 4/max. drive speed 0) input signal.

This function, autaic_SetInputStep5, is for setting Step5/MSP1(designate step 5/max. drive speed 1) input signal.

(1) **Function: autaic_SetInputStep4**

```
int autaic_SetInputStep4 (
    int PortNum,
    char nNodeId,
    BOOL bActLev
);
```

(2) **Function: autaic_SetInputStep5**

```
int autaic_SetInputStep5 (
    int PortNum,
    char nNodeId,
    BOOL bActLev
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select each logic level of Step4, 5/MSP0, 1(designate step 4, 5/max. drive speed 0, 1). (0: Low, 1: High)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.12 **autaic_SetInputMODE0 / autaic_SetInputMODE1**

This function, autaic_SetInputMODE0, is for setting MD0/HMD0(drive mode 0/home search mode 0) input signal.

This function, autaic_SetInputMODE1, is for setting MD1/HMD1(drive mode 1/home search mode 1) input signal.

(1) **Function: autaic_SetInputMODE0**

```
int autaic_SetInputMode0 (
    int PortNum,
    char nNodeID,
    BOOL bActLev
);
```

(2) **Function: autaic_SetInputMODE1**

```
int autaic_SetInputMode1 (
    int PortNum,
    char nNodeID,
    BOOL bActLev
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select each logic level of MD0, 1/HMD0, 1(drive mode 0, 1/home search mode 0, 1).
(0: Low, 1: High)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.13 *autaic_SetInputPAUSE*

This function, *autaic_SetInputPAUSE*, is for setting pause input signal.

(1) **Function**

```
int autaic_SetInputPAUSE (
    int PortNum,
    char nNodeID,
    BOOL bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select signal level of pause. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.14 **autaic_SetInputSTOP**

This function, autaic_SetInputSTOP, is for setting stop input signal.

(1) **Function**

```
int autaic_SetInputSTOP (
    int PortNum,
    char nNodeID,
    BOOL bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select signal level of stop. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.15 **autaic_SetInputEMG**

This function, autaic_SetInputEMG, is for setting EMG(emergency stop) input signal.

(1) **Function**

```
int autaic_SetInputEMG (
    int PortNum,
    char nNodeID,
    BOOL bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select signal level of EMG(emergency stop). (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.16 *autaic_SetInputHOME*

This function, *autaic_SetInputHOME*, is for setting home(home search) input signal.

(1) *Function*

```
int autaic_SetInputHOME (
    int PortNum,
    char nNodeID,
    BOOL bActLev
);
```

(2) *Parameter*

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select signal level of Home(home search). (0: Low, 1: High)

(3) *Return value*

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.17 **autaic_SetInputALMReset**

This function, autaic_SetInputALMReset, is for setting alarm reset input signal.

(1) **Function**

```
int autaic_SetInputALMReset (
    int PortNum,
    char nNodeID,
    BOOL bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select signal level of alarm reset. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.18 **autaic_SetInputServoOn**

This function, autaic_SetInputServoOn, is for setting Servo ON/OFF input signal.

(1) **Function**

```
int autaic_SetInputServoOn (
    int PortNum,
    char nNodeId,
    BOOL bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select signal level of Servo ON/OFF signal level. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.19 *autaic_SetLmtActLev*

This function, *autaic_SetLmtActLev*, is for setting $\pm$ Limit($\pm$ hardware limit) input signal.

(1) **Function**

```
int autaic_SetLmtActLev (
    int PortNum,
    char nNodeId,
    BOOL bLmtActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bLmtActLev: Select signal level of $\pm$ Limit($\pm$ hardware limit). (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.20 *autaic_SetInputLev0 to autaic_SetInputLev8*

This function, autaic_SetInputLev0 to autaic_SetInputLev8, is for setting IN0 to IN8(general input 0 to 8) input signal.

(1) **Function**

```
int autaic_SetInputLev0 to 8 (
    int PortNum,
    char nNodeId,
    BOOL bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select signal level of IN0 to IN8(general input 0 to 8). (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.21 **autaic_SetSDMode**

This function, autaic_SetSDMode, is for setting SD(deceleration mode) input signal.

(1) **Function**

```
int autaic_SetSDMode (
    int PortNum,
    char nNodeID,
    BOOL bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Select signal level of SD(deceleration mode). (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.22 *autaic_SetControlMode*

This function, *autaic_SetControlMode*, is for setting control mode.

(1) *Function*

```
int autaic_SetControlMode (
    int PortNum,
    char nNodeId,
    BOOL bMode
);
```

(2) *Parameter*

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bMode: Select the control mode. (0: Speed Filter, 1: Gain)

(3) *Return value*

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.23 *autaic_SetMotorDir*

This function, *autaic_SetMotorDir*, is for setting motro rotation direction.

(1) **Function**

```
int autaic_SetMotorDir (
    int PortNum,
    char nNodeId,
    BOOL bDir
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bDir: Select motor rotation direction. (0: CW, 1: CCW)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.24 *autaic_SetOutputMode*

This function, *autaic_SetOutputMode*, is for setting output mode during alarm.

(1) *Function*

```
int autaic_SetOutputMode (
    int PortNum,
    char nNodeId,
    BOOL bMode
);
```

(2) *Parameter*

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bMode: Select the output mode during alarm. (0: Maintain, 1: Reset)

(3) *Return value*

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.25 **autaic_GetLmtStopMod**

This function, autaic_GetLmtStopMod, is for loading the set value of parameter limit stop mode.

(1) **Function**

```
int autaic_GetLmtStopMod (
    int PortNum,
    char nNodeId,
    BOOL *bInstant
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bInstant: Load the set value of parameter limit stop mode. (0: Instant, 1: Slow)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.26 **autaic_GetSCurve**

This function, autaic_GetSCurve, is for loading the enable/disable value of S Curve(S curve acceleration/deceleration) of the set parameter.

(1) **Function**

```
int autaic_GetSCurve (
    int PortNum,
    char nNodeId,
    BOOL *bEnable
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bInstant: Load the enable/disable value of S Curve(S curve acceleration/deceleration). (0: Disable, 1: Enable)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.27 **autaic_GetInputFilter**

This function, autaic_GetInputFilter, is for loading the filter value of I/O Input software of the set parameter.

(1) **Function**

```
int autaic_GetInputFilter (
    int PortNum,
    char nNodeId,
    BOOL *bFilter
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bFilter: Load filter value of I/O Input software. (0: 10ms, 1: 1.5ms)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.28 **autaic_GetSofLmtEnable**

This function, `autaic_GetSofLmtEnable`, is for loading the enable/disable value of Software Limit (software limit) of the set parameter.

(1) **Function**

```
int autaic_GetSofLmtEnable (
    int PortNum,
    char nNodeId,
    BOOL *bEnable
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- bEnable: Load the enable/disable value of Software Limit (software limit). (0: Disable, 1: Enable)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.29 **autaic_GetPowHomStart**

This function, autaic_GetPowHomStart, is for loading the enable/disable value of home search automatically when power is ON of the set parameter.

(1) **Function**

```
int autaic_GetPowHomStart (
    int PortNum,
    char nNodeId,
    BOOL *bEnable
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bEnable: Load the enable/disable value of home search automatically when power is ON. (0: Disable, 1: Enable)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.30 **autaic_GetPowPgmStart**

This function, `autaic_GetPowPgmStart`, is for loading the enable/disable value of program starts automatically of the set parameter.

(1) **Function**

```
int autaic_GetPowPgmStart (
    int PortNum,
    char nNodeId,
    BOOL *bEnable
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- bEnable: Load the enable/disable value of program starts automatically. (0: Disable, 1: Enable)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.31 **autaic_GetStopCurrentFix**

This function, autaic_GetStopCurrentFix, is for loading the enable/disable value of fixed/not fixed stop current of the set parameter.

(1) **Function**

```
int autaic_GetStopCurrentFix (
    int PortNum,
    char nNodeId,
    BOOL *bEnable
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bEnable: Load the enable/disable value of fixed/not fixed stop current. (0: Disable, 1: Enable)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.32 **autaic_GetInputStart**

This function, `autaic_GetInputStart`, is for loading the level value of start(drive start) input signal input signal of the set parameter.

(1) **Function**

```
int autaic_GetInputStart (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- bActLev: Load the level value of start(drive start) input signal. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.33 **autaic_GetInputStep0 / autaic_GetInputStep1**

This function, autaic_GetInputStep0, is for loading the level value of Step0/+Run/+Jog (designate step 0/+continuous/+jog) input signal of the set parameter.

This function, autaic_GetInputStep1, is for loading the level value of Step1/-Run/-Jog (designate step 1/-continuous/-jog) input signal of the set parameter.

(1) **Function: autaic_GetInputStep0**

```
int autaic_GetInputStep0 (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(2) **Function: autaic_GetInputStep1**

```
int autaic_GetInputStep1 (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Load the signal level value of Step0, 1/±Run/±Jog(designate step 0, 1/±continuous/±jog) input signal. (0: Low, 1: High)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.34 **autaic_GetInputStep2 / autaic_GetInputStep3**

This function, autaic_GetInputStep2, is for loading the level value of Step2/SSP0(designate step 2/start drive speed 0) input signal of the set parameter.

This function, autaic_GetInputStep3, is for loading the level value of Step3/SSP1(designate step 3/start drive speed 1) input signal of the set parameter.

(1) **Function: autaic_GetInputStep2**

```
int autaic_GetInputStep2 (
    int PortNum,
    char nNodeID,
    BOOL * bActLev
);
```

(2) **Function: autaic_GetInputStep3**

```
int autaic_GetInputStep3 (
    int PortNum,
    char nNodeID,
    BOOL * bActLev
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Load the level value of Step2, 3/SSP0, 1(designate step 2, 3/start drive speed 0, 1) input signal. (0: Low, 1: High)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.35 **autaic_GetInputStep4 / autaic_GetInputStep5**

This function, autaic_GetInputStep4, is for loading the level value of Step4/MSP0(designate step 4/max. drive speed 0) input signal of the set parameter.

This function, autaic_GetInputStep5, is for loading the level value of Step5/MSP1(designate step 5/max. drive speed 1) input signal of the set parameter.

(1) **Function: autaic_GetInputStep4**

```
int autaic_GetInputStep4 (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(2) **Function: autaic_GetInputStep5**

```
int autaic_GetInputStep5 (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Load the level value of Step4, 5/MSP0, 1(designate step 4, 5/max. drive speed 0, 1) input signal. (0: Low, 1: High)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.36 **autaic_GetInputMODE0 / autaic_GetInputMODE1**

This function, autaic_GetInputMODE0, is for loading the level value of MD0/HMD0(drive mode 0/home search mode 0) input signal of the set parameter.

This function, autaic_GetInputMODE1, is for loading the level value of MD1/HMD1(drive mode 1/home search mode 1) input signal of the set parameter.

(1) **Function: autaic_GetInputMODE0**

```
int autaic_GetInputMODE0 (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(2) **Function: autaic_GetInputStep5**

```
int autaic_GetInputMODE1 (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Load the level value of MD0, 1/HMD0, 1(drive mode 0, 1/home search mode 0, 1) input signal (0: Low, 1: High)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.37 **autaic_GetInputPAUSE**

This function, autaic_GetInputPAUSE, is for loading the level value of pause input signal of the set parameter.

(1) **Function**

```
int autaic_GetInputPAUSE (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Load the level value of pause input signal. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.38 **autaic_GetInputSTOP**

This function, autaic_GetInputSTOP, is for loading the level value of stop input signal of the set parameter.

(1) **Function**

```
int autaic_GetInputSTOP (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Load the level value of stop input signal. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.39 **autaic_GetInputEMG**

This function, autaic_GetInputEMG, is for loading the level value of EMG(emergency stop) input signal of the set parameter.

(1) **Function**

```
int autaic_GetInputEMG (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Load the level value of EMG(emergency stop) input signal. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.40 **autaic_GetInputHOME**

This function, `autaic_GetInputHOME`, is for loading the level value of home (home search) input signal of the set parameter.

(1) **Function**

```
int autaic_GetInputHOME (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- bActLev: Load the level value of Home(home search) input signal. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.41 **autaic_GetInputALMReset**

This function, autaic_GetInputALMReset, is for loading the level value of alarm reset input signal of the set parameter.

(1) **Function**

```
int autaic_GetInputALMReset (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Load the level value of alarm reset input signal. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.42 **autaic_GetInputServoOn**

This function, `autaic_GetInputServoOn`, is for loading the level value of Servo ON/OFF input signal of the set parameter.

(1) **Function**

```
int autaic_GetInputServoOn (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- bActLev: Load the level value of Servo ON/OFF input signal. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.43 *autaic_GetLmtActLev*

This function, *autaic_GetLmtActLev*, is for loading the level value of $\pm$ Limit($\pm$ hardware limit) input signal of the set parameter.

(1) Function

```
int autaic_GetLmtActLev (
    int PortNum,
    char nNodeId,
    BOOL * bLevel
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bLevel: Load the level value of $\pm$ Limit($\pm$ hardware limit) input signal. (0: Low, 1: High)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.44 *autaic_GetInputLev0 to autaic_GetInputLev8*

This function, autaic_GetInputLev0 to autaic_GetInputLev8, is for loading the level value of IN0 to IN8(general input 0 to 8) input signal.

(1) **Function**

```
int autaic_GetInputLev0 to 8 (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Load the level value of IN0 to IN8(general input 0 to 8) input signal. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.45 **autaic_GetSDMode**

This function, autaic_GetSDMode , is for loading the level value of SD(deceleration mode) input signal.

(1) **Function**

```
int autaic_GetSDMode (
    int PortNum,
    char nNodeId,
    BOOL * bActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Load the level value of SD(deceleration mode) input signal. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.46 *autaic_GetControlMode*

This function, *autaic_GetControlMode*, is for loading the set value of control mode.

(1) *Function*

```
int autaic_GetControlMode (
    int PortNum,
    char nNodeId,
    BOOL * bMode
);
```

(2) *Parameter*

- PortNum : Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bMode: Load the set value of control mode. (0: Speed Filter, 1: Gain)

(3) *Return value*

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.47 **autaic_GetMotorDir**

This function, autaic_GetMotorDir , is for loading the set value of motor rotation direction.

(1) **Function**

```
int autaic_GetMotorDir (
    int PortNum,
    char nNodeId,
    BOOL * bDir
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bDir: Load the set value of motor rotation direction. (0: CW, 1: CCW)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.48 **autaic_GetOutputMode**

This function, `autaic_GetOutputMode`, is for loading the set value of output mode during alarm.

(1) **Function**

```
int autaic_GetOutputMode (
    int PortNum,
    char nNodeId,
    BOOL * bMode
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- bMode: Load the set value of output mode during alarm. (0: Maintain, 1: Reset)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.1.49 **autaic_GetBitSetGroup**

This function, autaic_GetBitSetGroup, is for loading all data set values of the bit setting group.

(1) **Function**

```
int autaic_GetBitSetGroup (
    int PortNum,
    char nNodeId,
    AIC_BITSET *pActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bActLev: Load all data set values of bit setting group.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2 Operation setting

3.2.1 *autaic_SetInitStartSpd*

This function, *autaic_SetInitStartSpd*, is for setting initial value of start drive speed (pps) for jog mode, continuous mode, absolute/relative position drive.

(1) Function

```
int autaic_SetInitStartSpd(
    int PortNum,
    char nNodeId,
    long lStartSpd
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- lStartSpd: Set start drive speed. (Set range: 1 to 600,000)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.2 **autaic_SetInitMaxSpd**

This function, `autaic_SetInitMaxSpd`, is for setting initial value of max. drive speed (pps) for jog mode, continuous mode, absolute/relative position drive.

(1) **Function**

```
int autaic_SetInitMaxSpd(
    int PortNum,
    char nNodeId,
    long lMaxSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- lMaxSpd: Set max. drive speed. (Set range: 1 to 600,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.3 **autaic_SetInitAccTime**

This function, `autaic_SetInitAccTime`, is for setting initial value of acceleration time for jog mode, continuous mode, absolute/relative position drive.

(1) **Function**

```
int autaic_SetInitAccTime (
    int PortNum,
    char nNodeId,
    int iAccTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAccTime: Set acceleration time. (Set range: 1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.4 **autaic_SetInitDecTime**

This function, `autaic_SetInitDecTime`, is for setting initial value of deceleration time for jog mode, continuous mode, absolute/relative position drive.

(1) **Function**

```
int autaic_SetInitDecTime (
    int PortNum,
    char nNodeId,
    int iDecTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- iDecTime: Set deceleration time. (Set range: 1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.5 **autaic_SetInitPosition**

This function, `autaic_SetInitPosition`, is for setting initial value of position(target position) for absolute/relative position drive.

(1) **Function**

```
int autaic_SetInitPosition (
    int PortNum,
    char nNodeID,
    long lPos
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- lPos: Set position(target position). (Set range: -2,147,483,648 to 2,147,483,647)

(3) **Return value**

Type	Definition	Return value	Description
Normal	<code>AIC_OK</code>	0	The function executes the command normally.
Input error	<code>AIC_INVALID_COMMAND</code>	1	Invalid command is entered.
	<code>AIC_INVALID_ADDRESS</code>	2	Invalid address is entered.
	<code>AIC_INVALID_ADDRESS_COUNT</code>	3	Invalid address counter is entered.
	<code>AIC_INVALID_PROCESS</code>	4	Invalid process
	<code>AIC_INVALID_PORT</code>	5	Entered port is not available or invalid port number is entered.
	<code>AIC_INVALID_BAUDRATE</code>	6	Invalid baudrate is entered.
	<code>AIC_INVALID_PARITYBIT</code>	7	Invalid parity bit is entered.
	<code>AIC_INVALID_STOPBIT</code>	8	Invalid stop bit is entered.
	<code>AIC_INVALID_NODE</code>	9	Invalid node number
	<code>AIC_INVALID_DATA</code>	10	Invalid data
	<code>AIC_INVALID_COMMUNICATION</code>	11	Communication error
	<code>AIC_CRC_ERROR</code>	12	CRC error
	<code>AIC_NO_RESPONSE_MESSAGE</code>	13	No response

3.2.6 **autaic_SetInitPgmStep**

This function, autaic_SetInitPgmStep, is for setting initial value of start step for index mode, program mode drive.

(1) **Function**

```
int autaic_SetInitPgmStep (
    int PortNum,
    char nNodeId,
    int iStep
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iStep: Set start step. (Set range: 0 to 255)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.7 **autaic_SetInitDrvSet**

This function, autaic_SetInitDrvSet, is for setting initial value of start drive speed (pps), max. drive speed (pps), acceleration time(msec), deceleration time(msec) for jog mode, continuous mode, absolute/relative position drive.

(1) **Function**

```
int autaic_SetInitDrvSet (
    int PortNum,
    char nNodeId,
    long lStartSpd,
    long lMaxSpd,
    int iAccTime,
    int iDecTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- lStartSpd: Set start drive speed. (Set range: 1 to 600,000)
- lMaxSpd: Set max. drive speed. (Set range: 1 to 600,000)
- iAccTime: Set acceleration time. (Set range: 1 to 10,000)
- iDecTime: Set deceleration time. (Set range: 1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.8 **autaic_SetStrSpdChg**

This function, autaic_SetStrSpdChg, is for overriding start drive speed (pps) during drive.

(1) **Function**

```
int autaic_SetStrSpdChg (
    int PortNum,
    char nNodeId,
    long lStartSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- lStartSpd: Set start drive speed. (Set range: 1 to 600,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.9 **autaic_SetMaxSpdChg**

This function, autaic_SetMaxSpdChg, is for overriding max. drive speed (pps) during drive.

(1) **Function**

```
int autaic_SetMaxSpdChg (
    int PortNum,
    char nNodeId,
    long lMaxSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- lMaxSpd: Set max. drive speed. (Set range: 1 to 600,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.10 **autaic_GetInitStartSpd**

This function, autaic_GetInitStartSpd, is for loading the initial value of the set start drive speed (pps).

(1) **Function**

```
int autaic_GetInitStartSpd (
    int PortNum,
    char nNodeId,
    long *IStartSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IStartSpd: Load start drive speed. (Set range: 1 to 600,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.11 **autaic_GetInitMaxSpd**

This function, `autaic_GetInitMaxSpd`, is for loading the initial value of the set max. drive speed (pps).

(1) **Function**

```
int autaic_GetInitMaxSpd (
    int PortNum,
    char nNodeId,
    long *IMaxSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- IMaxSpd: Load max. drive speed. (Set range: 1 to 600,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.12 **autaic_GetInitAccTime**

This function, autaic_GetInitAccTime, is for load the set value of acceleration time(msec).

(1) **Function**

```
int autaic_GetInitAccTime (
    int PortNum,
    char nNodeId,
    long *iAccTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAccTime: Load acceleration time. (Set range: 1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.13 **autaic_GetInitDecTime**

This function, `autaic_GetInitDecTime`, is for load the set value of deceleration time(msec).

(1) **Function**

```
int autaic_GetInitDecTime (
    int PortNum,
    char nNodeID,
    long *iDecTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- iDecTime: Load deceleration time. (Set range: 1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.14 **autaic_GetInitPosition**

This function, autaic_GetInitPosition, is for loading the initial value of the set target position.

(1) **Function**

```
int autaic_GetInitPosition (
    int PortNum,
    char nNodeId,
    long *IPos
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IPos: Load target position. (Set range: -2,147,483,648 to 2,147,483,647)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.15 **autaic_GetInitPgmStep**

This function, `autaic_GetInitPgmStep`, is for loading the initial value of the start step for index mode, program mode drive.

(1) **Function**

```
int autaic_GetInitPgmStep (
    int PortNum,
    char nNodeId,
    long *iStep
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- iStep: Load start step. (Set range: 0 to 255)

(3) **Return value**

Type	Definition	Return value	Description
Normal	<code>AIC_OK</code>	0	The function executes the command normally.
Input error	<code>AIC_INVALID_COMMAND</code>	1	Invalid command is entered.
	<code>AIC_INVALID_ADDRESS</code>	2	Invalid address is entered.
	<code>AIC_INVALID_ADDRESS_COUNT</code>	3	Invalid address counter is entered.
	<code>AIC_INVALID_PROCESS</code>	4	Invalid process
	<code>AIC_INVALID_PORT</code>	5	Entered port is not available or invalid port number is entered.
	<code>AIC_INVALID_BAUDRATE</code>	6	Invalid baudrate is entered.
	<code>AIC_INVALID_PARITYBIT</code>	7	Invalid parity bit is entered.
	<code>AIC_INVALID_STOPBIT</code>	8	Invalid stop bit is entered.
	<code>AIC_INVALID_NODE</code>	9	Invalid node number
	<code>AIC_INVALID_DATA</code>	10	Invalid data
	<code>AIC_INVALID_COMMUNICATION</code>	11	Communication error
	<code>AIC_CRC_ERROR</code>	12	CRC error
	<code>AIC_NO_RESPONSE_MESSAGE</code>	13	No response

3.2.16 *autaic_SetStartDrvSpd1 to autaic_SetStartDrvSpd5*

This function, autaic_SetStartDrvSpd1 to autaic_SetStartDrvSpd5, is for setting start drive speed 1 to 5 of the parameter.

(1) Function

```
int autaic_SetStartDrvSpd1 to 5 (
    int PortNum,
    char nNodeId,
    long IDrvSpd
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IDrvSpd: Set start drive speed. (Set range: 1 to 600,000)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.17 **autaic_SetMaxDrvSpd1 to autaic_SetMaxDrvSpd5**

This function, autaic_SetMaxDrvSpd1 to autaic_SetMaxDrvSpd5, is for setting max. drive speed 1 to 5 of the parameter.

(1) **Function**

```
int autaic_SetMaxDrvSpd1 to 5 (
    int PortNum,
    char nNodeId,
    long lDrvSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- lDrvSpd: Set max. drive speed. (Set range: 1 to 600,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.18 *autaic_SetDelayTime1 to autaic_SetDelayTime5*

This function, autaic_SetDelayTime1 to autaic_SetDelayTime5, is for setting wait time for executing next step after completing the step.

For TIM(wait) command, select one among delay time 1 to 5.

(1) **Function**

```
int autaic_SetDelayTime1 to 5 (
    int PortNum,
    char nNodeId,
    int iDTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iDTime: Set wait time. (Set range: 1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.19 **autaic_SetAccTime1 to autaic_SetAccTime5**

This function, autaic_SetAccTime1 to autaic_SetAccTime5, is for setting acceleration time(msec) of the parameter.

(1) **Function**

```
int autaic_SetAccTime1 to 5 (
    int PortNum,
    char nNodeId,
    int iAccTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAccTime: Set acceleration time. (Set range: 1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.20 *autaic_SetDecTime1 to autaic_SetDecTime5*

This function, autaic_SetDecTime1 to autaic_SetDecTime5, is for setting deceleration time(msec) of the parameter.

(1) Function

```
int autaic_SetDecTime1 to 5 (
    int PortNum,
    char nNodeId,
    int iDecTime
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iDecTime: Set deceleration time. (Set range: 1 to 10,000)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.21 **autaic_SetSCurvTime**

This function, `autaic_SetSCurvTime`, is for setting S curve time(S curve acceleration/deceleration time) of the parameter.

(1) **Function**

```
int autaic_SetSCurvTime (
    int PortNum,
    char nNodeId,
    int iSCTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- iSCTime: Set S curve Time(S curve acceleration/deceleration time). (Set range: 1 to 5,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.22 *autaic_SetSoftLmtPlus*

This function, *autaic_SetSoftLmtPlus*, is for setting high limit value of clock direction software limit.

(1) **Function**

```
int autaic_SetSoftLmtPlus (
    int PortNum,
    char nNodeId,
    long ISofLmtP
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- ISofLmtP: Set high limit value of software limit. (Set range: -2,147,483,648 to 2,147,483,647)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.23 **autaic_SetSoftLmtMinus**

This function, `autaic_SetSoftLmtMinus`, is for setting low limit value of counter clock direction software limit.

(1) **Function**

```
int autaic_SetSoftLmtMinus (
    int PortNum,
    char nNodeId,
    long lSofLmtM
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- lSofLmtM: Set low limit value of software limit. (Set range: -2,147,483,648 to 2,147,483,647)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.24 **autaic_SetONTime1 to autaic_SetONTime5**

This function, autaic_SetONTime1 to autaic_SetONTime5, is for setting output port ON time(msec).

ON time setting is available with “OPC” command at program mode.

(1) **Function**

```
int autaic_SetONTime1 to 5 (
    int PortNum,
    char nNodeId,
    int iONTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iONTime: Set output port ON time. (Set range: 1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.25 **autaic_SetCompareMode1 / autaic_SetCompareMode2**

This function, autaic_SetCompareMode1 / autaic_SetCompareMode2, is for setting comparison output mode.

(1) **Function: autaic_SetCompareMode1**

```
int autaic_SetCompareMode1 (
    int PortNum,
    char nNodeId,
    int iMode
);
```

(2) **Function: autaic_SetCompareMode2**

```
int autaic_SetCompareMode2 (
    int PortNum,
    char nNodeId,
    int iMode
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iMode: Set compare1, 2(compare output 1, 2) individually. (Set range: 0 to 3)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.26 **autaic_SetCompare1PulseWidth/autaic_SetCompare2PulseWidth**

This function, autaic_SetCompare1PulseWidth / autaic_SetCompare2PulseWidth, is for setting output signal width when compare 1, 2(comparison output 1, 2) is set as 3 individually.

(1) **Function: autaic_SetCompare1PulseWidth**

```
int autaic_SetCompare1PulseWidth (
    int PortNum,
    char nNodeId,
    int iWidth
);
```

(2) **Function: autaic_SetCompare2PulseWidth**

```
int autaic_SetCompare2PulseWidth (
    int PortNum,
    char nNodeId,
    int iWidth
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iWidth: Set the width (msec) of compare1, 2(comparison output 1, 2) output signal. (Set range: 1 to 1,000)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.27 **autaic_SetCompare1Period / autaic_SetCompare2Period**

This function, autaic_SetCompare1Period / autaic_SetCompare2Period, is for setting output signal period when compare 1, 2(comparison output 1, 2) is set as 3 individually.

(1) **Function: autaic_SetCompare1Period**

```
int autaic_SetCompare1Period (
    int PortNum,
    char nNodeId,
    long lPeriod
);
```

(2) **Function: autaic_SetCompare2Period**

```
int autaic_SetCompare2Period (
    int PortNum,
    char nNodeId,
    long lPeriod
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- lPeriod: Set the period (pulse) of compare1, 2(comparison output 1, 2) output signal. (Set range: 1 to 2,147,483,647)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.28 **autaic_SetCompare1Position / autaic_SetCompare2Position**

This function, autaic_SetCompare1Position / autaic_SetCompare2Position, is for setting trigger output signal position when compare 1, 2 (comparison output 1, 2) is set as 1 or 2 individually.

(1) **Function: autaic_SetCompare1Position**

```
int autaic_SetCompare1Position (
    int PortNum,
    char nNodeId,
    long IPos
);
```

(2) **Function: autaic_SetCompare2Position**

```
int autaic_SetCompare2Position (
    int PortNum,
    char nNodeId,
    long IPos
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IPos: Set the trigger output signal position. (Set range: -2,147,483,648 to 2,147,483,647)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.29 **autaic_SetResolution**

This function, `autaic_SetResolution`, is for setting resolution.

The pulses of 1 rotation input by resolution is 500, 1000, 1600, 2000, 3200, 3600, 5000, 6400, 7200, 10000.

(1) **Function**

```
int autaic_SetResolution (
    int PortNum,
    char nNodeId,
    int iResolution
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- iResolution: Set resolution(number of pulses per 1 rotation) of motor. (Set range: 0 to 9)

Set value	Pulses per 1 rotation (PPR)	Resolution
0	500	2.5
1	1000	5
2	1600	8
3	2000	10
4	3200	16
5	3600	18
6	5000	25
7	6400	32
8	7200	36
9	10000	50

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.30 *autaic_SetMotorACtResp*

This function, *autaic_SetMotorACtResp*, is for setting speed filter.

(1) *Function*

```
int autaic_SetMotorActResp (
    int PortNum,
    char nNodeId,
    int iActResp
);
```

(2) *Parameter*

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iActResp: Set speed filter. (Set range: 0 to 15)

Set value	Delay time
0	Not used
1	2ms
2	4ms
3	6ms
4	8ms
5	10ms
6	20ms
7	40ms
8	60ms
9	80ms
10	100ms
11	120ms
12	140ms
13	160ms
14	180ms
15	200ms

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.31 **autaic_SetStopCurrent**

This function, autaic_SetStopCurrent, is for setting stop current ratio value during stopping motor.

(1) **Function**

```
int autaic_SetStopCurrent (
    int PortNum,
    char nNodeID,
    int iStopCrt
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iStopCrt: Set stop current for %. (Set range: 20 to 100%)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.32 **autaic_GetStartDrvSpd1 to autaic_GetStartDrvSpd5**

This function, autaic_GetStartDrvSpd1 to autaic_GetStartDrvSpd5, is for loading the set value of Start Speed1 to 5(start drive speed 1 to 5) of the parameter.

(1) **Function**

```
int autaic_GetStartDrvSpd1 to 5 (
    int PortNum,
    char nNodeId,
    long *IDrvSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IDrvSpd: Save start speed(start drive speed). (1 to 600,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.33 *autaic_GetMaxDrvSpd1 to autaic_GetMaxDrvSpd5*

This function, autaic_GetMaxDrvSpd1 to autaic_GetMaxDrvSpd5, is for loading the set value of Max Speed1 to 5(max. drive speed 1 to 5) of the parameter.

(1) Function

```
int autaic_GetMaxDrvSpd1 to 5 (
    int PortNum,
    char nNodeId,
    long *IDrvSpd
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IDrvSpd: Save max speed(max. drive speed). (1 to 600,000)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.34 **autaic_GetDelayTime1 to autaic_GetDelayTime5**

This function, autaic_GetDelayTime1 to autaic_GetDelayTime5, is for loading the set value of Delay Time1 to 5 (wait time 1 to 5) of the parameter.

(1) **Function**

```
int autaic_GetDelayTime1 to 5 (
    int PortNum,
    char nNodeId,
    int *iDTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iDTime: Save delay time(wait time). (1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.35 *autaic_GetAccTime1 to autaic_GetAccTime5*

This function, autaic_GetAccTime1 to autaic_GetAccTime5, is for loading the set value of acceleration time 1 to 5 of the parameter.

(1) **Function**

```
int autaic_GetAccTime1 to 5 (
    int PortNum,
    char nNodeId,
    int *iAccTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAccTime: Save acceleration time. (1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.36 *autaic_GetDecTime1 to autaic_GetDecTime5*

This function, autaic_GetDecTime1 to autaic_GetDecTime5, is for loading the set deceleration time 1 to 5 of the parameter.

(1) Function

```
int autaic_GetDecTime1 to 5 (
    int PortNum,
    char nNodeId,
    int *iDecTime
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iDecTime: Save deceleration time. (1 to 10,000)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.37 **autaic_GetSCurvTime**

This function, `autaic_GetSCurvTime`, is for loading the set value of S curve time(S curve acceleration/deceleration time) of the parameter.

(1) **Function**

```
int autaic_GetSCurvTime (
    int PortNum,
    char nNodeId,
    int *iSCTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- iSCTime: Save S curve time(S curve acceleration/deceleration time). (1 to 5,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.38 **autaic_GetSofLmtPlus**

This function, autaic_GetSofLmtPlus, is for loading the high limit set value of clock direction software limit of the parameter.

(1) **Function**

```
int autaic_GetSofLmtPlus (
    int PortNum,
    char nNodeId,
    long *ISofLmtP
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- ISofLmtP: Save high limit value of software limit. (-2,147,483,648 to 2,147,483,647)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.39 *autaic_GetSofLmtMinus*

This function, *autaic_GetSofLmtMinus*, is for loading the low limit set value of counter clock direction software limit of the parameter.

(1) *Function*

```
int autaic_GetSofLmtMinus (
    int PortNum,
    char nNodeId,
    long *ISofLmtM
);
```

(2) *Parameter*

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- ISofLmtM: Save low limit value of software limit. (-2,147,483,648 to 2,147,483,647)

(3) *Return value*

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.40 *autaic_GetONTime1 to autaic_GetONTime5*

This function, autaic_GetONTimea1 to autaic_GetONTime5, is for loading the set value of output port ON time 1 to 5 of the parameter.

(1) Function

```
int autaic_GetONTime1 to 5 (
    int PortNum,
    char nNodeId,
    int *iONTime
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
- Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iONTime: Save output port ON time. (1 to 10,000)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.41 **autaic_GetCompareMode1 / autaic_GetCompareMode2**

This function, autaic_GetCompareMode1 / autaic_GetCompareMode2, is for loading the set value of compare 1, 2(comparison output 1, 2) of the parameter.

(1) **Function: autaic_GetCompareMode1**

```
int autaic_GetCompareMode1 (
    int PortNum,
    char nNodeId,
    int *iMode
);
```

(2) **Function: autaic_GetCompareMode2**

```
int autaic_GetCompareMode2 (
    int PortNum,
    char nNodeId,
    int *iMode
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iMode: Save compare 1, 2(comparison output 1, 2). (0 to 3)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.42 **autaic_GetCompare1PulseWidth/autaic_GetCompare2PulseWidth**

This function, autaic_GetCompare1PulseWidth/autaic_GetCompare2PulseWidth, is for loading the set value of output signal width of compare 1, 2 (comparison output 1, 2) of the parameter.

(1) **Function: autaic_GetCompare1PulseWidth**

```
int autaic_GetCompare1PulseWidth (
    int PortNum,
    char nNodeId,
    int *iWidth
);
```

(2) **Function: autaic_GetCompare2PulseWidth**

```
int autaic_GetCompare2PulseWidth (
    int PortNum,
    char nNodeId,
    int *iWidth
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iMode: Save signal width of compare 1, 2 (comparison output 1, 2) output signal. (1 to 1,000)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.43 **autaic_GetCompare1Period / autaic_GetCompare2Period**

This function, autaic_GetCompare1Period/autaic_GetCompare2Period, is for loading the set value of output signal period of compare 1, 2(comparison output 1, 2).

(1) **Function: autaic_GetCompare1Period**

```
int autaic_GetCompare1Period (
    int PortNum,
    char nNodeId,
    long *IPeriod
);
```

(2) **Function: autaic_GetCompare2Period**

```
int autaic_GetCompare2Period (
    int PortNum,
    char nNodeId,
    long *IPeriod
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IPeriod: Save output signal period (pulse) of compare 1, 2(comparison output 1, 2) (1 to 2,147,483,647)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.44 **autaic_GetCompare1Position / autaic_GetCompare2Position**

This function, autaic_GetCompare1Position/autaic_GetCompare2Position, is for loading the position set value of trigger output signal of compare 1, 2(comparison output 1, 2) of the parameter.

(1) **Function: autaic_GetCompare1Position**

```
int autaic_GetCompare1Position (
    int PortNum,
    char nNodeId,
    long *IPos
);
```

(2) **Function: autaic_GetCompare2Position**

```
int autaic_GetCompare2Position (
    int PortNum,
    char nNodeId,
    long *IPos
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IPos: Save position setting of trigger output signal of compare 1, 2(comparison output 1, 2).
(-2,147,483,648 to 2,147,483,647)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.45 *autaic_GetResolution*

This function, *autaic_GetResolution*, is for loading the set value of resolution.

(1) *Function*

```
int autaic_GetResolution (
    int PortNum,
    char nNodeId,
    int *iResolution
);
```

(2) *Parameter*

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iResolution: Save resolution(pulses per 1 rotation) of motor. (0 to 9)

(3) *Return value*

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.46 **autaic_GetMotorActResp**

This function, autaic_GetMotorActResp, is for loading the set value of speed filter of the parameter.

(1) **Function**

```
int autaic_GetMotorActResp (
    int PortNum,
    char nNodeId,
    int *iActResp
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iActResp: Save speed filter. (0 to 15)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.47 **autaic_GetStopCurrent**

This function, autaic_GetStopCurrent, is for loading the set value of stop current for (%).

(1) **Function**

```
int autaic_GetStopCurrent (
    int PortNum,
    char nNodeID,
    int *iStopCrt
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iStopCrt: Save stop current for (%). (20 to 100%)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.2.48 *autaic_GetActGroup*

This function, *autaic_GetActGroup*, is for loading all operation set value of the parameter.

(1) Function

```
int autaic_ActGroup (
    int PortNum,
    char nNodeId,
    AIC_ACTGROUP *pAGroup
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- pAGroup: Save operation parameter settings.

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3 Home search setting

3.3.1 *autaic_SetInitHomeRunMode*

This function, *autaic_SetInitHomeRunMode*, is for setting the initial value of home search command types during home search drive.

(1) Function

```
int autaic_SetInitHomeRunMode (
    int PortNum,
    char nNodeId,
    int iMode
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iMode: Select home search command type.

Set value	Home search
0	General home search
1	Limit home search
2	Zero point home search
3	Torque home search

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.2 **autaic_GetInitHomeRunMode**

This function, autaic_GetInitHomeRunMode, is for loading the set value of home search command types of the parameter.

(1) **Function**

```
int autaic_GetInitHomeRunMode (
    int PortNum,
    char nNodeId,
    int *iMode
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iMode: Load home search command type.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.3 **autaic_SetHomeMaxSpd**

This function, `autaic_SetHomeMaxSpd`, is for setting Home Search High Speed(home search max. drive speed).

(1) **Function**

```
int autaic_SetHomeMaxSpd (
    int PortNum,
    char nNodeId,
    long lHomeMaxSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- lHomeMaxSpd: Set home search high speed(home search max. drive speed) (pps)
(Set range: 1 to 600,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.4 **autaic_SetHomeStartSpd**

This function, autaic_SetHomeStartSpd, is for setting Home Search Low Speed(home search start drive speed).

(1) **Function**

```
int autaic_SetHomeStartSpd (
    int PortNum,
    char nNodeId,
    long lHomeStartSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- lHomeStartSpd: Set home search low speed(home search start drive speed) (pps). (Set range: 1 to 600,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.5 **autaic_SetHomeAccTime**

This function, autaic_SetHomeAccTime, is for setting home search acceleration time.

(1) **Function**

```
int autaic_SetHomeAccTime (
    int PortNum,
    char nNodeID,
    int iAccTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAccTime: Set home search acceleration time (msec) (Set range: 1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.6 **autaic_SetHomeDecTime**

This function, autaic_SetHomeDecTime, is for setting home search deceleration time.

(1) **Function**

```
int autaic_SetHomeDecTime (
    int PortNum,
    char nNodeId,
    int iDecTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iDecTime: Set home search deceleration time (msec). (Set range: 1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.7 **autaic_SetHomeDir**

This function, autaic_SetHomeDir, is for setting motor rotation direction for home search drive.

(1) **Function**

```
int autaic_SetHomeDir (
    int PortNum,
    char nNodeID,
    BOOL bDir
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bDir: Set motor rotation direction for home search drive. (0: clock direction, 1: counter clock direction)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.8 **autaic_SetHomeOffset**

This function, autaic_SetHomeOffset, is for moving for the set distance of home search offset and stopping after home search drive end.

(1) **Function**

```
int autaic_SetHomeOffset (
    int PortNum,
    char nNodeId,
    long lOffset
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- lOffset: Set home search offset. (Set range: -2,147,483,648 to 2,147,483,647)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.9 *autaic_SetHomePos*

This function, *autaic_SetHomePos*, is for changing position value as Position Set (home search position) after home search drive.

(1) *Function*

```
int autaic_SetHomePos (
    int PortNum,
    char nNodeID,
    long lPos
);
```

(2) *Parameter*

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- lPos: Set position set(home search position). (Set range: -2,147,483,648 to 2,147,483,647)

(3) *Return value*

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.10 **autaic_SetORGSigLev**

This function, autaic_SetORGSigLev, is for setting input signal level of ORG(home sensor).

(1) **Function**

```
int autaic_SetORGSigLev (
    int PortNum,
    char nNodeId,
    BOOL bLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bLev: Select input signal level of ORG(home sensor). (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.11 **autaic_SetHomeTorque**

This function, `autaic_SetHomeTorque`, is for setting home search torque during torque home search.

(1) **Function**

```
int autaic_SetHomeTorque (
    int PortNum,
    char nNodeId,
    int iTorque
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- iTorque: Set home search torque value (%). (Set range: 20 to 100%)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.12 **autaic_GetHomeMaxSpd**

This function, autaic_GetHomeMaxSpd, is for loading the set value of home search high speed(home search max. drive speed).

(1) **Function**

```
int autaic_GetHomeMaxSpd (
    int PortNum,
    char nNodeId,
    long *lHomeMaxSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- lHomeMaxSpd: Save home search high speed(home search max. drive speed). (1 to 600,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.13 **autaic_GetHomeStartSpd**

This function, autaic_GetHomeStartSpd, is for loading home search low speed(home search start drive speed).

(1) **Function**

```
int autaic_GetHomeStartSpd (
    int PortNum,
    char nNodeId,
    long *lHomeStartSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- lHomeStartSpd: Save home search low speed(home search start drive speed).(1 to 600,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.14 **autaic_GetHomeAccTime**

This function, autaic_GetHomeAccTime, is for loading the set value of home search acceleration time.

(1) **Function**

```
int autaic_GetHomeAccTime (
    int PortNum,
    char nNodeId,
    int *iAccTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAccTime: Save home search acceleration time. (1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.15 **autaic_GetHomeDecTime**

This function, `autaic_GetHomeDecTime`, is for loading the set value of home search deceleration time.

(1) **Function**

```
int autaic_GetHomeDecTime (
    int PortNum,
    char nNodeID,
    int *iDecTime
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- iDecTime: Save home search deceleration time. (1 to 10,000)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.16 *autaic_GetHomeDir*

This function, *autaic_GetHomeDir*, is for loading the set value of home search direction (motor rotation direction during home search).

(1) Function

```
int autaic_GetHomeDir (
    int PortNum,
    char nNodeId,
    BOOL *bDir
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bDir: Save home search direction(motor rotation direction during home search). (0: clock direction, 1: counter clock direction)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.17 **autaic_GetHomeOffset**

This function, autaic_GetHomeOffset, is for loading the set value of home search offset.

(1) **Function**

```
int autaic_GetHomeOffset (
    int PortNum,
    char nNodeID,
    long *lOffset
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- lOffset: Save home search offset. (-2,147,483,648 to 2,147,483,647)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.18 *autaic_GetHomePos*

This function, *autaic_GetHomePos*, is for loading the set value of home search position (home search target position).

(1) Function

```
int autaic_GetHomePos (
    int PortNum,
    char nNodeId,
    long *IPos
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IPos: Save home search position (home search target position). (-2,147,483,648 to 2,147,483,647)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.19 **autaic_GetORGSigLev**

This function, `autaic_GetORGSigLev`, is for loading the set value of ORG(home sensor) input signal level.

(1) **Function**

```
int autaic_GetORGSigLev (
    int PortNum,
    char nNodeID,
    BOOL *bLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- bLev: Save level setting of ORG(home sensor) input signal. (0: Low, 1: High)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.20 *autaic_GetHomeTorque*

This function, *autaic_GetHomeTorque*, is for loading the set value of home search torque.

(1) **Function**

```
int autaic_GetHomeTorque (
    int PortNum,
    char nNodeId,
    int * iTorque
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iTorque: Save home search torque for (%). (20 to 100%)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

3.3.21 **autaic_GetHomeGroup**

This function, autaic_GetHomeGroup, is for loading all data set values of home search parameter group.

(1) **Function**

```
int autaic_GetHomeGroup (
    int PortNum,
    char nNodeId,
    AIC_HOMEGROUP *pHGroup
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- pHGroup: Save data setting of home search parameter group.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4 I/O Control

4.1 *autaic_SetUserOut0 to autaic_SetUserOut9*

This function, *autaic_SetUserOut0* to *autaic_SetUserOut9*, is for ON/OFF general output 0 to 9 of I/O connector(CN3).

(1) Function

```
int autaic_SetUserOut0 to 9 (
    int PortNum,
    char nNodeId,
    BOOL bOn
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Select the status of general output 0 to 9 individual. (0: Off, 1: On)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response



Note

There is no OUT 9 for AiC-D-B (built-in brake type).

4.2 **autaic_GetUserOut0 to autaic_GetUserOut9**

This function, autaic_GetUserOut0 to autaic_GetUserOut9, is for loading the status of general output 0 to 9 of I/O connector(CN3).

(1) **Function**

```
int autaic_GetUserOut0 to 9 (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of general output 0 to 9. (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response



Note

There is no OUT 9 for AiC-D-B (built-in brake type).

4.3 **autaic_GetUserOutGroup**

This function, autaic_GetUserOutGroup, is for loading the status of general output of I/O connector(CN3).

(1) **Function**

```
int autaic_GetUserOutGroup (
    int PortNum,
    char nNodeId,
    AIC_USEROUTPUTGROUP *pOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- pOn: Save the status of all general outputs. (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.4 **autaic_exGetDrvStart**

This function, autaic_exGetDrvStart, is for loading the status of start(drive start) of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetDrvStart(
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of start(drive start). (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.5 **autaic_exGetSTEP0 to autaic_exGetSTEP5**

This function, autaic_exGetSTEP0 to autaic_exGetSTEP5, is for loading the status of Step0/+Run/+Jog, Step1/-Run/-Jog, Step2/SSP0, Step3/SSP1, Step4/MSP0, Step5/MSP1 of I/O connector(CN3).

(1) Function

```
int autaic_exGetSTEP0 to 5 (
    int PortNum,
    char nNodeID,
    BOOL *bOn
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeID
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn
 - STEP0: Save the status of Step0/+Run/+Jog. (0: Off, 1: On)
 - STEP1: Save the status of Step1/-Run/-Jog. (0: Off, 1: On)
 - STEP2: Save the status of Step2/SSP0. (0: Off, 1: On)
 - STEP3: Save the status of Step3/SSP1. (0: Off, 1: On)
 - STEP4: Save the status of Step4/MSP0. (0: Off, 1: On)
 - STEP5: Save the status of Step5/MSP1. (0: Off, 1: On)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.6 **autaic_exGetMODE0 / autaic_exGetMODE1**

This function, autaic_exGetMODE0 / autaic_exGetMODE1, is for loading the status of MD0, 1/HMD0, 1 of I/O connector(CN3).

(1) **Function: autaic_exGetMODE0**

```
int autaic_exGetMODE0 (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Function: autaic_exGetMODE1**

```
int autaic_exGetMODE1 (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of MD0, 1/HMD0, 1. (0: Off, 1: On)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.7 **autaic_exGetPause**

This function, autaic_exGetPause, is for loading the status of pause of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetPause (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of pause. (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.8 **autaic_exGetSlowStop**

This function, autaic_exGetSlowStop, is for loading the status of stop of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetSlowStop (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of stop. (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.9 **autaic_exGetEMGStop**

This function, autaic_exGetEMGStop, is for loading the stauts of EMG(emergency stop) of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetEMGStop (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of EMG (emergency stop). (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.10 **autaic_exGetHomeRun**

This function, `autaic_exGetHomeRun`, is for loading the status of Home(home search) of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetHomeRun (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of Home(home search). (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.11 **autaic_exGetORG**

This function, autaic_exGetORG, is for loading the status ORG(home sensor) of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetORG (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of ORG(home sensor). (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.12 **autaic_exGetALMReset**

This function, autaic_exGetALMReset, is for loading the status of alarm reset of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetALMReset (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of alarm reset. (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.13 **autaic_exGetServoOn**

This function, autaic_exGetServoOn, is for loading the status of Servo ON/OFF of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetServoOn (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of Servo ON/OFF (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.14 **autaic_exGetLimitPlus**

This function, `autaic_exGetLimitPlus`, is for loading the status of +Limit(+ hardware limit) of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetLimitPlus (
    int PortNum,
    char nNodeID,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of +Limit(+ hardware limit). (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.15 **autaic_exGetLimitMinus**

This function, autaic_exGetLimitMinus, is for loading the status of –Limit (-hardware limit) of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetLimitMinus (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of -Limit(-hardware limit). (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.16 **autaic_exGetUserInput 0 to autaic_exGetUserInput8**

This function, autaic_exGetUserInput 0 to autaic_exGetUserInput8, is for loading the status of general input 0 to 8 of I/O connector(CN3).

(1) Function

```
int autaic_exGetUserInput 0 to 8 (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of general input 0 to 8. (0: Off, 1: On)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.17 **autaic_exGetSDmode**

This function, autaic_exGetSDmode, is for loading the status of SD(deceleration mode) of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetSDmode (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of SD(deceleration mode). (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.18 **autaic_exGetALMSignal**

This function, autaic_exGetALMSignal, is for loading the status of alarm output of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetALMSignal (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of alarm output. (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.19 **autaic_exGetInposition**

This function, autaic_exGetInposition, is for loading the status of In-Position output of I/O connector(CN3).

(1) **Function**

```
int autaic_exGetInposition (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of In-Position output. (0: Off, 1: On)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.20 **autaic_exGetCompare1 / autaic_exGetCompare2**

This function, autaic_exGetCompare1 / autaic_exGetCompare2, is for loading the status of Compare 1, 2 (comparison output 1, 2) of I/O connector (CN3).

(1) **Function: autaic_exGetCompare1**

```
int autaic_exGetCompare1 (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(2) **Function: autaic_exGetCompare2**

```
int autaic_exGetCompare2 (
    int PortNum,
    char nNodeId,
    BOOL *bOn
);
```

(3) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- bOn: Save the status of compare 1, 2 (comparison output 1, 2). (0: Off, 1: On)

(4) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

4.21 **autaic_GetExInputGroup**

This function, autaic_GetExInputGroup, is for loading the status of all external input.

(1) **Function**

```
int autaic_GetBitSetGroup (
    int PortNum,
    char nNodeId,
    AIC_BITSET *pActLev
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- pActLev: Saves the status of all external input.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

5 Movement control

5.1 *autaic_ContPulseCW*

This function, *autaic_ContPulseCW*, is for outputting drive pulse continuously to clock direction until entering stop command.

(1) Function

```
int autaic_ContPulseCW (
    int PortNum,
    char nNodeID
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

5.2 **autaic_ContPulseCCW**

This function, `autaic_ContPulseCCW`, is for outputting drive pulse continuously to counter clock direction until entering stop command.

(1) **Function**

```
int autaic_ContPulseCCW (
    int PortNum,
    char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId

Select the node ID. The range of node ID is 0 to 31.

When the node ID is out of the range, `AIC_INVALID_NODE(9)` is returned.

Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

5.3 **autaic_ABSMove**

This function, autaic_ABSMove, is for moving to the absolute position for the designated distance based on the home.

(1) **Function**

```
int autaic_ABSMove (
    int PortNum,
    char nNodeID
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
 - Select the node ID. The range of node ID is 0 to 31.
 - When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
 - Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

5.4 **autaic_INCMove**

This function, `autaic_INCMove`, is for moving to the relative position for the designated distance based on the current position.

(1) **Function**

```
int autaic_INCMove (
    int PortNum,
    char nNodeID
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID

Select the node ID. The range of node ID is 0 to 31.

When the node ID is out of the range, `AIC_INVALID_NODE(9)` is returned.

Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

5.5 **autaic_HomeModeRun**

This function, autaic_HomeModeRun, is for driving home search according to the the designated home search mode.

(1) **Function**

```
int autaic_HomeModeRun (
    int PortNum,
    char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6 Program Control

6.1 *autaic_IndexModeRun*

This function, *autaic_IndexModeRun*, is for driving the selected one “ABS”, “INC” command step among program mode command.

(1) Function

```
int autaic_IndexModeRun (
    int PortNum,
    char nNodeId
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.2 **autaic_PgmModeRun**

This function, `autaic_PgmModeRun`, is for driving program mode.
It drives the saved each command from the designated step sequentially.

(1) **Function**

```
int autaic_PgmModeRun (
    int PortNum,
    char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId

Select the node ID. The range of node ID is 0 to 31.

When the node ID is out of the range, `AIC_INVALID_NODE(9)` is returned.

Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.3 **autaic_PgmPause**

This function, autaic_PgmPause, is for pausing the driving step as program mode after completing.

(1) **Function**

```
int autaic_PgmPause (
    int PortNum,
    char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.4 **autaic_PgmStop**

This function, `autaic_PgmStop`, is for stopping the driving step as program mode after completing.

(1) **Function**

```
int autaic_PgmStop (
    int PortNum,
    char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId

Select the node ID. The range of node ID is 0 to 31.

When the node ID is out of the range, `AIC_INVALID_NODE(9)` is returned.

Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.5 **autaic_PgmABS**

This function, autaic_PgmABS, is for moving the absolute position to the designated distance based on the home.

(1) **Function**

```
int autaic_PgmABS (
    int PortNum,
    char nNodeId,
    int nStepNo,
    int ParaStartSpd,
    long StartSpd,
    int ParaMaxSpd,
    long MaxSpd,
    int ParaAccel,
    int Accel,
    int ParaDecel,
    int Decel,
    long IPos,
    BOOL SCurveEnable,
    int iSCurvTime,
    BOOL ContinueEnable
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- nStepNo: Enter the step number to register command. (Set range: 0 to 255)
- ParaStartSpd
 - Enter start drive speed of parameter. (Set range: 1 to 6)
 - 1 to 5 input
 - : Drives with the set start drive speed 1 to 5 parameter during motor drive.
 - 6 input
 - : Drives with the entered start drive speed at StartSpd during motor drive.
- StartSpd: Enter start drive speed. (Set range: 1 to 600,000).
- ParaMaxSpd
 - Enter max. drive speed. (Set range: 1 to 6).
 - 1 to 5 input
 - : Drives with the set max. drive speed 1 to 5 during motor drive.
 - 6 input
 - : Drives with the entered max. drive speed at MaxSpd during motor drive.
- MaxSpd: Enter max. drive speed. (Set range: 1 to 600,000)
- ParaAccel
 - Enter acceleration time. (Set range: 1 to 6)
 - 1 to 5 input
 - : Drives with the set acceleration time 1 to 5 during motor drive.
 - 6 input
 - : Drives with the entered acceleration time at Accel during motor drive.
- Accel: Enter acceleration time. (Set range: 1 to 10000)
- ParaDecel

- Enter deceleration time. (Set range: 1 to 6)
 - 1 to 5 input
: Drives with the set deceleration time 1 to 5 during motor drive.
 - 6 input
: Drives with the entered deceleration time of Decel during motor drive.
- Decel: Enter deceleration time. (Set range: 1 to 10000)
- IPos: Enter the coordinate to be moved. (Set range: -2,147,483,648 to 2,147,483,647)
- SCurveEnable
Set enable/disable of S curve acceleration/deceleration. (0: Disable, 1: Enable)
- iSCurvTime
For using S curve acceleration/deceleration, set S curve acceleration/deceleration time.
(Set range: 1 to 5,000)
- ContinueEnable
Set enable/disable of continuation.

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.6 **aic_PgmINC**

This function, `autaic_PgmStop`, is for moving the relative position to the designated distance based on the current position.

(1) **Function**

```
int autaic_PgmINC (
    int PortNum,
    char nNodeId,
    int nStepNo,
    int ParaStartSpd,
    long StartSpd,
    int ParaMaxSpd,
    long MaxSpd,
    int ParaAccel,
    int Accel,
    int ParaDecel,
    int Decel,
    long IPos,
    BOOL SCurveEnable,
    int iSCurvTime,
    BOOL ContinueEnable
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)
- ParaStartSpd
Enter start drive speed. (Set range: 1 to 6)
 - 1 to 5 input
: Drives with the set start drive speed 1 to 5 during motor drive.
 - 6 input
: Drives with the entered start drive speed at `StartSpd` during motor drive.
- StartSpd: Enter start drive speed. (Set range: 1 to 600,000)
- ParaMaxSpd
Enter max. drive speed. (Set range: 1 to 6)
 - 1 to 5 input
: Drives with the set max. drive speed 1 to 5 during motor drive.
 - 6 input
: Drives with the entered max. drive speed at `MaxSpd` during motor drive.
- MaxSpd: Enter max. drive speed. (Set range: 1 to 600,000)
- ParaAccel
Enter acceleration time. (Set range: 1 to 6)
 - 1 to 5 input
: Drives with the set acceleration time 1 to 5 during motor drive.
 - 6 input
: Drives with the entered acceleration time at `Accel` during motor drive.
- Accel: Enter acceleration time. (Set range: 1 to 10000)
- ParaDecel

Enter deceleration time. (Set range: 1 to 6)

- 1 to 5 input
: Drives with the set deceleration time 1 to 5 during motor drive.
- 6 input
: Drives with the entered deceleration time at Decel during motor drive.
- Decel: Enter deceleration time. (Set range: 1 to 10000)
- IPos: Enter the coordinate to be moved..
(Set range: -2,147,483,648 to 2,147,483,647)
- SCurveEnable
Set enable/disable of S curve acceleration/deceleration. (0: Disable, 1: Enable)
- iSCurvTime
For using S curve acceleration/deceleration, set S curve acceleration/deceleration time.
(Set range: 1 to 5,000)
- ContinueEnable
Set enable/disable of continuation.

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.7 **autaic_PgmHOM**

This function, autaic_PgmHOM, is for driving home search.

(1) **Function**

```
int autaic_PgmHOM (
    int PortNum,
    char nNodeId,
    int nStepNo,
    int iHomeMode
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)
- iHomeMode: Set home search mode. (0: general home search, 1: limit home search, 2: zero point home search, 3: torque home search)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.8 **autaic_PgmICJ**

This function, `autaic_PgmICJ`, is for jumping the designated step when input port of input condition command is activated, or executing the next step when it is not activated.

(1) **Function**

```
int autaic_PgmICJ (
    int PortNum,
    char nNodeId,
    int nStepNo,
    int nJumpStep,
    int nInputPtNo
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)
- nJumpStep: Enter the step number to be jumped. (Set range: 0 to 255)
- nInputPtNo: Enter input port number. (Set range: 0 to 8)

(3) **Return value**

Type	Definition	Return value	Description
Normal	<code>AIC_OK</code>	0	The function executes the command normally.
Input error	<code>AIC_INVALID_COMMAND</code>	1	Invalid command is entered.
	<code>AIC_INVALID_ADDRESS</code>	2	Invalid address is entered.
	<code>AIC_INVALID_ADDRESS_COUNT</code>	3	Invalid address counter is entered.
	<code>AIC_INVALID_PROCESS</code>	4	Invalid process
	<code>AIC_INVALID_PORT</code>	5	Entered port is not available or invalid port number is entered.
	<code>AIC_INVALID_BAUDRATE</code>	6	Invalid baudrate is entered.
	<code>AIC_INVALID_PARITYBIT</code>	7	Invalid parity bit is entered.
	<code>AIC_INVALID_STOPBIT</code>	8	Invalid stop bit is entered.
	<code>AIC_INVALID_NODE</code>	9	Invalid node number
	<code>AIC_INVALID_DATA</code>	10	Invalid data
	<code>AIC_INVALID_COMMUNICATION</code>	11	Communication error
	<code>AIC_CRC_ERROR</code>	12	CRC error
	<code>AIC_NO_RESPONSE_MESSAGE</code>	13	No response

6.9 **autaic_PgmIRD**

This function, autaic_PgmIRD, is for jumping the next step when input port of input wait command is activated, or waiting the current step when it is not activated until activated.

(1) **Function**

```
int autaic_PgmIRD (
    int PortNum,
    char nNodeID,
    int nStepNo,
    int nInputPtNo
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)
- nInputPtNo: Enter input port number. (Set range: 0 to 8)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.10 **autaic_PgmOPC**

This function, autaic_PgmOPC, is for turning ON/OFF the designated output port as output port ON/OFF command.

(1) **Function**

```
int autaic_PgmOPC (
    int PortNum,
    char nNodeId,
    int nStepNo,
    int nOutPtNo,
    BOOL bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)
- nOutPtNo: Enter output port number. (Set range – AiC-D: 0 to 9, AiC-D-B: 0 to 8)
- bOn: Select output port ON/OFF status. (0: OFF, 1: ON)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.11 **autaic_PgmOPT**

This function, autaic_PgmOPT, is for turning ON the set output port of output port ON pulse command during the ON time.

(1) **Function**

```
int autaic_PgmOPT (
    int PortNum,
    char nNodeId,
    int nStepNo,
    int nOutPtNo,
    int ParaOnTim,
    int iOnTim,
    BOOL bOn
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)
- nOutPtNo: Enter output port number. (Set range – AiC-D: 0 to 9, AiC-D-B: 0 to 8)
- ParaOnTim
Enter output port ON time. (Set range: 1 to 6)
 - 1 to 5 input
: Turns ON the output port for the set ON time 1 to 5.
 - 6 input
: Turns ON the output port for the entered time at iOnTim.
- iOnTim: Enter output port ON time. (Set range: 1 to 10,000)
- bOn: Select output port ON pulse status. (0: OFF, 1: ON)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.12 **autaic_PgmJMP**

This function, autaic_PgmJMP, is for jumping the designated step by jump command.

(1) **Function**

```
int autaic_PgmJMP (
    int PortNum,
    char nNodeId,
    int nStepNo,
    int nJumpStep
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)
- nJumpStep: Enter the step number to be jumped. (Set range: 0 to 255)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.13 **autaic_PgmREP**

This function, autaic_PgmREP, is for executing repeat from the next step of repeat start command to the "RPE(repeat end)" command for the set times.

(1) **Function**

```
int autaic_PgmREP (
    int PortNum,
    char nNodeId,
    int nStepNo,
    int nRepCnt
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)
- nRepCnt
Enter the number of repeats. (Set range: 1 to 255)
The register number of repeat end command must be below the repeat start command.
Repeat loop is available up to 3 times.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.14 **autaic_PgmRPE**

This function, autaic_PgmRPE, is end command of “REP” as repeat end command.

(1) **Function**

```
int autaic_PgmRPE (
    int PortNum,
    char nNodeId,
    int nStepNo
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.15 **autaic_PgmEND**

This function, autaic_PgmEND, is for ending program mode drive.
Must enter the command at the end of program.

(1) **Function**

```
int autaic_PgmEND (
    int PortNum,
    char nNodeId,
    int nStepNo
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.16 **autaic_PgmPOS**

This function, autaic_PgmPOS, is for setting position value.

(1) **Function**

```
int autaic_PgmPOS (
    int PortNum,
    char nNodeId,
    int nStepNo,
    long lPos
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)
- lPos: Enter the position value to be set. (Set range: -2,147,483,648 to 2,147,483,647)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.17 **autaic_PgmTIM**

This function, autaic_PgmTIM, is for executing wait command during the set time as the wait command.

(1) **Function**

```
int autaic_PgmTIM (
    int PortNum,
    char nNodeId,
    int nStepNo,
    int ParaDelayTim,
    int DelayTim
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)
- ParaDelayTim
Enter wait time. (Set range: 1 to 6)
1 to 5 input: Sets the set wait time 1 to 5.
6 input: Sets the entered time at DelayTim(wait time).
- DelayTim: Enter wait time. (Set range: 1 to 10000).

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.18 **autaic_PgmCMP**

This function, `autaic_PgmCMP`, is for setting Compare 1, 2 (comparison output 1, 2) parameter.

(1) **Function**

```
int autaic_PgmCMP (
    int PortNum,
    char nNodeID,
    int nStepNo,
    int iCompareNo,
    int iCompMode,
    int iPulseWidth,
    long IPulsePeriod,
    long IPos
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
 - Select the node ID. The range of node ID is 0 to 31.
 - When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- nStepNo: Enter the step number to set command. (Set range: 0 to 255)
- iCompareNo: Set comparison output port. (Set range: 1 to 3)
- iCompareMode
 - Sets comparison output mode.
 - 0: Not used (Not used, outputs [L])
 - 1: Outputs [H] when the current absolute position is bigger than or same as 'Compare1 Position'
 - 2: Outputs [H] when the current absolute position is smaller than or same as 'Compare1 Position'
 - 3: Outputs the set pulse width of 'Compare Pulse Width' with the set period of 'Compare1 Period'
- iPulseWidth
 - In case of "Compare Mode"=3, set width (msec) of output signal.
 - (Set range: 1 to 1000)
- IPulsePeriod
 - In case of "Compare Mode"=3, set period (pulse) of output signal.
 - (Set range: 1 to 2,147,483,647)
- IPulsePos
 - In case of "Compare Mode"=1 or "Compare Mode"=2, set trigger output signal position.
 - (Set range: -2,147,483,648 to 2,147,483,647)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.19 **autaic_PgmDelAll**

This function, autaic_PgmDelAll, is for deleting all program mode data of 0 to 255 steps.

(1) **Function**

```
int autaic_DelPgmDelAll (
    int PortNum,
    char nNodeId
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When the node ID is out of the range, AIC_INVALID_NODE(9) is returned.
Enter Broadcast (0x81) and data transfers to every connected AiC-D(-B) with PC by broadcast function.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.20 **autaic_PgmDelStep**

This function, autaic_PgmDelStep, is for deleting program mode data of the designated step.

(1) **Function**

```
int autaic_PgmDelStep (
    int PortNum,
    char nNodeId,
    int nStepNo
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- nStepNo: Enter step number to be deleted. (Set range: 0 to 255)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

6.21 **autaic_GetPgmData**

This function, autaic_GetPgmData, is for loading the registered program mode data information at the set 0 to 255 step.

(1) **Function**

```
Int autaic_GetPgmData (
    int PortNum,
    char nNodeId,
    int nStepNo,
    AIC_PGMDATA *pPgmData
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- pPgmData: Save the set program mode data information of 0 to 255 step.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

7 Monitoring Data

7.1 *autaic_GetDriverMode*

This function, *autaic_GetDriverMode*, is for loading the current drive mode value.

(1) Function

```
int autaic_GetDriverMode (
    int PortNum,
    char nNodeId,
    int *iDrvMode
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iDrvMode: Save the current value of drive mode.
(0: wait, 1: index, 2: jog, 3: continuous, 4: program, 5: home, 6: general)

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

7.2 **autaic_GetLogicalPos**

This function, autaic_GetLogicalPos, is for loading the current command position coordinate value.

(1) **Function**

```
int autaic_GetLogicalPos (
    int PortNum,
    char nNodeId,
    long *IPos
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IPos: Save the command position coordinate value.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

7.3 **autaic_GetActualPos**

This function, autaic_GetActualPos, is for loading the current actual position coordinate value.

(1) **Function**

```
int autaic_GetActualPos (
    int PortNum,
    char nNodeId,
    long *IPos
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IPos: Save the actual position coordinate value.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

7.4 **autaic_GetLogicalDrvSpd**

This function, autaic_GetLogicalDrvSpd, is for loading the current command drive speed.

(1) **Function**

```
int autaic_GetLogicalDrvSpd (
    int PortNum,
    char nNodeId,
    long *IDrvSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IDrvSpd: Save the current command max. drive speed value.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

7.5 **autaic_GetActualDrvSpd**

This function, autaic_GetActualDrvSpd, is for loading the current actual drive speed.

(1) **Function**

```
int autaic_GetActualDrvSpd (
    int PortNum,
    char nNodeId,
    long *IDrvSpd
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- IDrvSpd: Save the current actual max. drive speed.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

7.6 **autaic_GetMotorRPM**

This function, autaic_GetMotorRPM, is for loading rotation speed.

(1) **Function**

```
int autaic_GetMotorRPM (
    int PortNum,
    char nNodeId,
    int *iMotorRPM
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iMotorRPM: Save rotation speed (RPM).

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

7.7 **autaic_GetCurPgmNo**

This function, autaic_GetCurPgmNo, is for loading the executing program mode step number value.

(1) **Function**

```
int autaic_GetCurPgmNo (
    int PortNum,
    char nNodeId,
    int *iCurPgmNo
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iCurPgmNo: Save the executing program mode step number.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

7.8 **autaic_GetErrorSt**

This function, autaic_GetErrorSt, is for loading the alarm status of current drive.

(1) **Function**

```
int autaic_GetErrorSt (
    int PortNum,
    char nNodeId,
    AIC_ERRORSTATE *pError
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- pError: Save the alarm value of the current drive.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

7.9 **autaic_GetParallelI01**

This function, autaic_GetParallelI01, is for loading I/O status.

(drive start, STEP0/+Run/+Jog, STEP1/-Run/-Jog, STEP2/SSP0, STEP3/SSP1, STEP4/MSP0, STEP5/MSP1)

(1) **Function**

```
int autaic_GetParallelI01 (
    int PortNum,
    char nNodeID,
    PARALLELSTATE1 *pState
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- pState: Save input/output signal status. (0: OFF, 1: ON)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

7.10 **autaic_GetParallel02**

This function, autaic_GetParallel02, is for loading I/O status.

(+Limit, - Limit, IN0 to 8, deceleration mode)

(1) **Function**

```
int autaic_GetParallel02 (
    int PortNum,
    char nNodeId,
    PARALLELSTATE2 *pState
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- pState: Save input/output signal status. (0: OFF, 1: ON)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

7.11 **autaic_GetParallelI03**

This function, autaic_GetParallelI03, is for loading I/O status.

(Alarm, In-Position, Compare 1, Compare 2)

(1) **Function**

```
int autaic_GetParallelI03 (
    int PortNum,
    char nNodeId,
    PARALLELSTATE3 *pState
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- pState: Save input/output signal status. (0: OFF, 1: ON)

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

7.12 **autaic_MonitorData**

This function, autaic_MonitorData, is for loading all data status of monitoring group.

(1) **Function**

```
int autaic_MonitorData (
    int PortNum,
    char nNodeId,
    AIC_MonitorData *pMData
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- pMData: Save all data status of monitoring group.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

8 Product Information

8.1 *autaic_GetSofVer*

This function, *autaic_GetSofVer*, is for loading the applied software version.

(1) Function

```
int autaic_GetSofVer (
    int PortNum,
    char nNodeId,
    AIC_SOFTVERSION *pVersion
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- pVersion: Set software version.

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

8.2 **autaic_GetModName**

This function, autaic_GetModName, is for loading motor model name.

(1) **Function**

```
int autaic_GetModName (
    int PortNum,
    char nNodeId,
    AIC_SOFTWARE_VERSION *pVersion
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- pVersion: Save motor model name.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

8.3 **autaic_GetCoilStatusStartAddress**

This function, autaic_GetCoilStatusStartAddress, is for loading CoilStatus start address.

(1) **Function**

```
int autaic_GetCoilStatusStartAddress (
    int PortNum,
    char nNodeId,
    int *iAddr
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAddr: Save CoilStatus start address.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

8.4 **autaic_GetCoilStatusQuantity**

This function, `autaic_GetCoilStatusQuantity`, is for loading the number of CoilStatus addresses.

(1) Function

```
int autaic_GetCoilStatusQuantity (
    int PortNum,
    char nNodeId,
    int *iAddr
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, `AIC_INVALID_NODE(9)` is returned.
- iAddr: Save the number of CoilStatus addresses.

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

8.5 **autaic_GetInputStatusStartAddress**

This function, autaic_GetInputStatusStartAddress, is for loading InputStatus start address.

(1) **Function**

```
int autaic_GetInputStatusStartAddress (
    int PortNum,
    char nNodeId,
    int *iAddr
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAddr: Save InputStatus start address.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

8.6 **autaic_GetInputStatusQuantity**

This function, `autaic_GetInputStatusQuantity`, is for loading the number of InputStatus addresses.

(1) **Function**

```
int autaic_GetInputStatusQuantity (
    int PortNum,
    char nNodeId,
    int *iAddr
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAddr: Save the number of InputStatus addresses.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

8.7 **autaic_GetHoldingRegisterStartAddress**

This function, autaic_GetHoldingRegisterStartAddress, is for loading Holding Register start address.

(1) **Function**

```
int autaic_GetHoldingRegisterStartAddress (
    int PortNum,
    char nNodeId,
    int *iAddr
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAddr: Save Holding Register start address.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

8.8 **autaic_GetHoldingRegisterQuantity**

This function, autaic_GetHoldingRegisterQuantity, is for loading the number of Holding Register addresses.

(1) **Function**

```
int autaic_GetHoldingRegisterQuantity (
    int PortNum,
    char nNodeId,
    int *iAddr
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAddr: Save the number of Holding Register addresses.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

8.9 **autaic_GetInputRegisterStartAddress**

This function, autaic_GetInputRegisterStartAddress, is for loading Input Register start address.

(1) Function

```
int autaic_GetInputRegisterStartAddress (
    int PortNum,
    char nNodeId,
    int *iAddr
);
```

(2) Parameter

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAddr: Save Input Register start address.

(3) Return value

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

8.10 **autaic_GetInputRegisterQuantity**

This function, autaic_GetInputRegisterQuantity, is for loading the number of Input Register addresses.

(1) **Function**

```
int autaic_GetInputRegisterQuantity (
    int PortNum,
    char nNodeId,
    int *iAddr
);
```

(2) **Parameter**

- PortNum: Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 0 to 31.
When it is out of the ID range, AIC_INVALID_NODE(9) is returned.
- iAddr: Save the number of Input Register addresses.

(3) **Return value**

Type	Definition	Return value	Description
Normal	AIC_OK	0	The function executes the command normally.
Input error	AIC_INVALID_COMMAND	1	Invalid command is entered.
	AIC_INVALID_ADDRESS	2	Invalid address is entered.
	AIC_INVALID_ADDRESS_COUNT	3	Invalid address counter is entered.
	AIC_INVALID_PROCESS	4	Invalid process
	AIC_INVALID_PORT	5	Entered port is not available or invalid port number is entered.
	AIC_INVALID_BAUDRATE	6	Invalid baudrate is entered.
	AIC_INVALID_PARITYBIT	7	Invalid parity bit is entered.
	AIC_INVALID_STOPBIT	8	Invalid stop bit is entered.
	AIC_INVALID_NODE	9	Invalid node number
	AIC_INVALID_DATA	10	Invalid data
	AIC_INVALID_COMMUNICATION	11	Communication error
	AIC_CRC_ERROR	12	CRC error
	AIC_NO_RESPONSE_MESSAGE	13	No response

9 *Example of Library Usage*

9.1 *Reset*

```
#include <stdio.h>
#include <windows.h>
#include "lib\include\Library.h"
#pragma comment(lib,"lib\\x64\\AiCLibrary.lib")
#define PORTNO 6

void main()
{
    int stat=0; // AiC communication connection function
                // Return value: returns AIC_OK when command executes normally.
                // Function: To be connected Serial Port Number, Serial Port Baudrate,
                //           Serial Port Paritibit, Serial Port Stopbit
                // stat: Check the connectable comport status.

    for (int i=0; i<=PORTNO; i++)
    {

        switch(i)
        {
            case 0: stat = autaic_Open(0, AIC_BAUD_115200, None, STOPBIT1);
                    break;
            case 1: stat = autaic_Open(1, AIC_BAUD_115200, None, STOPBIT1);
                    break;
            case 2: stat = autaic_Open(2, AIC_BAUD_115200, None, STOPBIT1);
                    break;
            case 3: stat = autaic_Open(3, AIC_BAUD_115200, None, STOPBIT1);
                    break;
            case 4: stat = autaic_Open(4, AIC_BAUD_115200, None, STOPBIT1);
                    break;
            case 5: stat = autaic_Open(5, AIC_BAUD_115200, None, STOPBIT1);
                    break;
            case 6: stat = autaic_Open(6, AIC_BAUD_115200, None, STOPBIT1);
                    break;
            case 7: stat = autaic_Open(7, AIC_BAUD_115200, None, STOPBIT1);
                    break;
            case 8: stat = autaic_Open(8, AIC_BAUD_115200, None, STOPBIT1);
```

```
        break;
case 9: stat = autaic_Open(9, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 10: stat = autaic_Open(10, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 11: stat = autaic_Open(11, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 12: stat = autaic_Open(12, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 13: stat = autaic_Open(13, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 14: stat = autaic_Open(14, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 15: stat = autaic_Open(15, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 16: stat = autaic_Open(16, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 17: stat = autaic_Open(17, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 18: stat = autaic_Open(18, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 19: stat = autaic_Open(19, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 20: stat = autaic_Open(20, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 21: stat = autaic_Open(21, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 22: stat = autaic_Open(22, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 23: stat = autaic_Open(23, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 24: stat = autaic_Open(24, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 25: stat = autaic_Open(25, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 26: stat = autaic_Open(26, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 27: stat = autaic_Open(27, AIC_BAUD_115200, None, STOPBIT1);
        break;
```

```
case 28: stat = autaic_Open(28, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 29: stat = autaic_Open(29, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 30: stat = autaic_Open(30, AIC_BAUD_115200, None, STOPBIT1);
        break;
case 31: stat = autaic_Open(31, AIC_BAUD_115200, None, STOPBIT1);
        break;
}
if (stat == AIC_OK)
{
    printf("MESSAGE: Found and open 'AiC Series (ID=%d)' ComPort\n", i);
}
}

autaic_Close(i);
}
```

9.2 **Stop, End**

```
#include <stdio.h>
#include <windows.h>
#include "lib\include\Library.h"
#pragma comment(lib,"lib\\x64\\AiCLibrary.lib")
#define PORTNO 6

void main()
{
    int Flag=0; //error check flag

    autaic_Open(PORTNO, AIC_BAUD_115200, None, STOPBIT1); //port OPEN
    Flag=autaic_Close(PORTNO); // port CLOSE

    if(Flag!=AIC_OK)
    {
        printf("error! retrun value: %d\n", Flag);
    }
}
```

9.3 **Parameter setting**

```
#include <stdio.h>
#include <windows.h>
#include "lib\include\Library.h"
#pragma comment(lib, "lib\\x64\\AiCLibrary.lib")
#define PORTNO 6

void main()
{
    autaic_Open(PORTNO, AIC_BAUD_115200, None, STOPBIT1); //port OPEN

    AIC_BITSET ActLev;
    AIC_BITSET *pActLev = &ActLev;

    autaic_GetBitSetGroup(PORTNO, Node01, pActLev);
    //loads bit set group

    printf("%d\n", pActLev->bLmtStopMod); //limit stop mode
    printf("%d\n", pActLev->bSCurve); //S curve acceleration/deceleration
    printf("%d\n", pActLev->bInputFilter); //select Input filter
    printf("%d\n", pActLev->bSofLmtEnable); //software limit
    printf("%d\n", pActLev->bPowHomStart);
    //power ON home search auto start
    printf("%d\n", pActLev->bPowPgmStart);
    // power ON program auto start
    printf("%d\n", pActLev->bStopCurrentFix); //stop current fixed method
    printf("%d\n", pActLev->bDrvStart);
    //Index/Program mode start signal level setting
    printf("%d\n", pActLev->bSTEPSL0);
    //Step0/+Run/+Jog signal level setting
    printf("%d\n", pActLev->bSTEPSL1);
    //Step1/-Run/-Jog signal level setting
    printf("%d\n", pActLev->bSTEPSL2); //Step2/SSP0 signal level setting
    printf("%d\n", pActLev->bSTEPSL3); //Step3/SSP1 signal level setting
    printf("%d\n", pActLev->bSTEPSL4); //Step4/MSP0 signal level setting
    printf("%d\n", pActLev->bSTEPSL5); //Step5/MSP1 signal level setting
    printf("%d\n", pActLev->bMODE0); //drive mode 0/home search mode 0 signal
    level setting
    printf("%d\n", pActLev->bMODE1); //drive mode 1/home search mode 1 signal
```

```

    level setting
    printf("%d\n", pActLev->bPause); //pause signal level setting
    printf("%d\n", pActLev->bStop); //stop signal level setting
    printf("%d\n", pActLev->bEMG); //emergency stop signal level setting
    printf("%d\n", pActLev->bHOME); //home search start signal level setting
    printf("%d\n", pActLev->bALMReset); //alarm reset signal level setting
    printf("%d\n", pActLev->bServoOn); //servo on/off signal level setting
    printf("%d\n", pActLev->bLmtActLev); //limit signal level setting
    printf("%d\n", pActLev->bUserInput0); //general input 0 signal level setting
    printf("%d\n", pActLev->bUserInput1); //general input 1 signal level setting
    printf("%d\n", pActLev->bUserInput2); //general input 2 signal level setting
    printf("%d\n", pActLev->bUserInput3); //general input 3 signal level setting
    printf("%d\n", pActLev->bUserInput4); //general input 4 signal level setting
    printf("%d\n", pActLev->bUserInput5); //general input 5 signal level setting
    printf("%d\n", pActLev->bUserInput6); //general input 6 signal level setting
    printf("%d\n", pActLev->bUserInput7); //general input 7 signal level setting
    printf("%d\n", pActLev->bUserInput8); //general input 8 signal level setting
    printf("%d\n", pActLev->bSDMode); //SD signal level setting

    if(pActLev->iErrorState!=AIC_OK)
    {
        printf("error! retrun value: %d\n", pActLev->iErrorState);
    }

    autaic_Close(PORTNO);
}

```

9.4 **Movement control**

```
#include <stdio.h>
#include <windows.h>
#include "lib\include\Library.h"
#pragma comment(lib, "lib\\x64\\AiCLibrary.lib")
#define PORTNO 6

void main()
{
    int Flag=0; //error check flag
    long IStartSpeed=100; //start drive speed
    long IMaxSpeed=1000; //max. drive speed
    int iAcctime=100; //acceleration time(msec)
    int iDectime=100; //deceleration time(msec)
    long ILocate=10000; //movement position coordinate

    autaic_Open(PORTNO, AIC_BAUD_115200, None, STOPBIT1); //port OPEN
    autaic_SetInitDrvSet(PORTNO, Node01, IStartSpeed, IMaxSpeed, iAcctime, iDectime);
    //start drive speed, max. drive speed, acceleration time, deceleration time set

    autaic_SetInitPosition(PORTNO, Node01, ILocate); //movement position coordinate set
    Flag=autaic_ABSMove(PORTNO, Node01); //absolute position movement command
    execution

    if(Flag!=AIC_OK)
    {
        printf("error! retrun value: %d\n", Flag);
    }

    autaic_Close(PORTNO);
}
```

9.5 **Program mode**

```

#include <stdio.h>
#include <windows.h>
#include "lib\include\Library.h"
#pragma comment(lib,"lib\\x64\\AiCLibrary.lib")
#define PORTNO 6

void main()
{
    int iStepNo=0; //step number

    autaic_Open(PORTNO, AIC_BAUD_115200, None, STOPBIT1); //port OPEN
    AIC_PGMDATA PgmData;
    AIC_PGMDATA *pPgmData = &PgmData;

    for (int i=0; i < 256; i++) //0 to 255 step
    {
        autaic_GetPgmData(PORTNO, Node01, i, pPgmData);
        //load the set Program mode information

        printf("%d\n", pPgmData->iCommand);
        //the set Program mode command
        "used command: ABS, INC, HOM, ICJ, IRD, OPC, OPT,
            JMP, REP, RPE, END, POS, TIM"

        printf("%d\n", pPgmData->ParaStartSpd);
        //start drive speed  (1 to 5: Parameter start drive speed ,
        6: user Input start drive speed )
        "used command: ABS, INC"

        printf("%d\n", pPgmData->SCurveEnable);
        //S curve acceleration/deceleration enable/disable (0: disable, 1: enable)
        "used command: ABS, INC"

        printf("%d\n", pPgmData->ParaMaxSpd);
        //max. drive speed  (1 to 5: Parameter max. drive speed ,
        6: user Input max. drive speed )
        "used command: ABS, INC"
    }
}

```

```
printf("%d\n", pPgmData->ParaAccel);  
//acceleration time (1 to 5: Parameter acceleration time,  
6: user Input acceleration time)  
"used command: ABS, INC"  
  
printf("%d\n", pPgmData->ParaDecel);  
//deceleration time (1 to 5: Parameter deceleration time,  
6: user Input deceleration time)  
"used command: ABS, INC"  
  
printf("%d\n", pPgmData->StartSpd);  
//user Input start drive speed  
"used command: ABS, INC"  
  
printf("%d\n", pPgmData->MaxSpd);  
//user Input max. drive speed  
"used command: ABS, INC"  
  
printf("%d\n", pPgmData->Accel);  
//user Input acceleration time(msec)  
"used command: ABS, INC"  
  
printf("%d\n", pPgmData->Decel);  
//user Input deceleration time(msec)  
"used command: ABS, INC"  
  
printf("%d\n", pPgmData->SCurv);  
//S curve acceleration/deceleration time  
"used command: ABS, INC"  
  
printf("%d\n", pPgmData->IPos);  
//position coordinate  
"used command: ABS, INC, POS"  
  
printf("%d\n", pPgmData->iHomeMode);  
//home search type  
"used command: HOM"
```

```
printf("%d\n", pPgmData->nInputPtNo);  
//Input port number  
"used command: ICJ, IRD"
```

```
printf("%d\n", pPgmData->nJumpStep);  
//step number to be jumped  
"used command: ICJ, JMP"
```

```
printf("%d\n", pPgmData->nOutPtNo);  
//output port number  
"used command: OPC, OPT"
```

```
printf("%d\n", pPgmData->bOn);  
//ON/OFF  
"used command: OPC, OPT"
```

```
printf("%d\n", pPgmData->ParaOnTim);  
//ON time (1 to 5: Parameter ON time,  
6: user Input ON time)  
"used command: OPT"
```

```
printf("%d\n", pPgmData->iOnTim);  
//user Input ON time  
"used command: OPT"
```

```
printf("%d\n", pPgmData->nRepCnt);  
//repeat times  
"used command: REP"
```

```
printf("%d\n", pPgmData->ParaDelayTim);  
//wait time (1 to 5: Parameter wait time,  
6: user Input wait time)  
"used command: TIM"
```

```
printf("%d\n", pPgmData->DelayTim);  
//user Input wait time(msec)  
"used command: TIM"
```

```
printf("%d\n", pPgmData->iCompareNo);  
//comparison output number(1 to 2)  
"used command: CMP"  
  
printf("%d\n", pPgmData-> iCompareMode);  
//comparison output mode(0 to 3)  
"used command: CMP "  
  
printf("%d\n", pPgmData->iPulseWidth);  
//comparison output width  
"used command: CMP "  
  
printf("%d\n", pPgmData->iPulsePeriod);  
//comparison output period  
"used command: CMP "  
}  
  
if(pPgmData->iErrorState!=AIC_OK)  
{  
    printf("error! retrun value: %d\n", Flag);  
}  
  
autaic_Close(PORTNO);  
}
```

9.6 **Monitoring data**

```
#include <stdio.h>
#include <windows.h>
#include "lib\include\Library.h"
#pragma comment(lib,"lib\\x64\\AiCLibrary.lib")
#define PORTNO 6

void main()
{
    autaic_Open(PORTNO, AIC_BAUD_115200, None, STOPBIT1); //port OPEN

    AIC_MonitorData MData;
    AIC_MonitorData *pMData = &MData;

    autaic_MonitorData(PORTNO, Node01, pMData);
    //load monitoring data status

    printf("%ld\n", pMData->ILogicalPos); //command position coordinate
    printf("%ld\n", pMData->IActualPos); //actual position coordinate
    printf("%ld\n", pMData->ILogicalSpd); //command drive speed
    printf("%ld\n", pMData->IActualSpd); //actual drive speed
    printf("%d\n", pMData->iMotorRPM); //motor rotation speed(RPM)
    printf("%d\n", pMData->iCurStepNo); //driving program step number
    printf("%d\n", pMData->iDrvMode); //drive mode
    printf("%d\n", pMData->bOverCurErr); //over current error
    printf("%d\n", pMData->bOverSpdErr); //over speed error
    printf("%d\n", pMData->bPosEstErr); //position follow error
    printf("%d\n", pMData->bOverloadErr); //over load error
    printf("%d\n", pMData->bOverheatErr); //over heat error
    printf("%d\n", pMData->bMotorConErr); //motor connection error
    printf("%d\n", pMData->bEncoderConErr); //encoder connection error
    printf("%d\n", pMData->bEmgErr); //return volt error
    printf("%d\n", pMData->bEmgErr); //motor alignment error
    printf("%d\n", pMData->bEmgErr); //command speed error
    printf("%d\n", pMData->bEmgErr); //Input voltage error
    printf("%d\n", pMData->bEmgErr); //In-Position error
    printf("%d\n", pMData->bMemoryErr); //memory error
    printf("%d\n", pMData->bEmgErr); //emergency stop error
    printf("%d\n", pMData->bPgmErr); //Program mode error
```

```
printf("%d\n", pMData->bInxErr); //Index mode error
printf("%d\n", pMData->bHomeSearchErr); //home search mode error
printf("%d\n", pMData->bSofLmtErrP); //+software limit error
printf("%d\n", pMData->bSofLmtErrM); //-software limit error
printf("%d\n", pMData->bHardLmtErrP); //+hardware limit error
printf("%d\n", pMData->bHardLmtErrM); //-hardware limit error
printf("%d\n", pMData->bOverloadWarn); //over load warning
printf("%d\n", pMData->bDrvStart); //drive start
printf("%d\n", pMData->bSTEP[0]); //Step0/+Run/+Jog
printf("%d\n", pMData->bSTEP[1]); //Step1/-Run/-Jog
printf("%d\n", pMData->bSTEP[2]); //Step2/SSP0
printf("%d\n", pMData->bSTEP[3]); //Step3/SSP1
printf("%d\n", pMData->bSTEP[4]); //Step4/MSP0
printf("%d\n", pMData->bSTEP[5]); //Step5/MSP1
printf("%d\n", pMData->bMODE[0]); //drive mode designate 0
printf("%d\n", pMData->bMODE[1]); //drive mode designate 1
printf("%d\n", pMData->bPause); //pause
printf("%d\n", pMData->bStop); //stop
printf("%d\n", pMData->bEMG); //emergency stop
printf("%d\n", pMData->bHOME); //home search
printf("%d\n", pMData->bALMReset); //alarm reset
printf("%d\n", pMData->bServoOn); //servo ON/OFF
printf("%d\n", pMData->bORG); //home sensor
printf("%d\n", pMData->bLmtP); //+Limit sensor
printf("%d\n", pMData->bLmtM); //-Limit sensor
printf("%d\n", pMData->bUserInput[0]); //general input0
printf("%d\n", pMData->bUserInput[1]); //general input1
printf("%d\n", pMData->bUserInput[2]); //general input2
printf("%d\n", pMData->bUserInput[3]); //general input3
printf("%d\n", pMData->bUserInput[4]); //general input4
printf("%d\n", pMData->bUserInput[5]); //general input5
printf("%d\n", pMData->bUserInput[6]); //general input6
printf("%d\n", pMData->bUserInput[7]); //general input7
printf("%d\n", pMData->bUserInput[8]); //general input8
printf("%d\n", pMData->bSDMode); //deceleration mode
printf("%d\n", pMData->bAIMSignal); //alarm output
printf("%d\n", pMData->bInposition); //In-Position output
printf("%d\n", pMData->bCompare[1]); //comparison output1
printf("%d\n", pMData->bCompare[2]); //comparison output2
```

```
        if(pState->iErrorState!=AIC_OK)
        {
            printf("error! retrun value: %d\n", pMData->iErrorState);
        }

        autaic_Close(PORTNO);
    }
```

9.7 **Product information**

```
#include <stdio.h>
#include <windows.h>
#include "lib\include\Library.h"
#pragma comment(lib,"lib\\x64\\AiCLibrary.lib")
#define PORTNO 6

void main()
{
    autaic_Open(PORTNO, AIC_BAUD_115200, None, STOPBIT1); //port OPEN

    AIC_SOFTWARE_VERSION Version;
    AIC_SOFTWARE_VERSION *pVersion = &Version;

    autaic_GetSofVer (PORTNO, Node01, pVersion); //Loads firmware version.

    printf("%s\n",pVersion->cSofVer);

    if(pVersion->iErrorState!=AIC_OK)
    {
        printf("error! retrun value: %d\n", pVersion->iErrorState);
    }

    autaic_Close(PORTNO);
}
```

Autonics

Sensors & Controllers

www.autonics.com

Distributor



■ Major Products

·Photoelectric Sensors·Fiber Optic Sensors·Door Sensors·Door Side Sensors·Area Sensors
·Proximity Sensors·Pressure Sensors·Connectors·Sockets·Rotary Encoders·Panel Meters
·Counters·Timers·Temperature Controllers·SSRs·Power Controllers·Sensor Controllers
·Graphic/Logic Panels·Temperature/Humidity Transducers·Switching Mode Power Supplies
·Stepper Motors·Drivers·Motion Controllers·I/O Terminal Blocks & Cables·Display Units
·Control Switches·Lamps·Buzzers·Field Network Devices·Tachometer/Pulse(Rate) Meters
·Laser Marking System(Fiber, CO₂, Nd:YAG)·Laser Welding/Cutting System

■ Any proposal for a product improvement and development: Product@autonics.com

■ Corporate Headquarters

18 Bansong-ro, 513 Beon-gil, Haeundae-gu, Busan, South Korea 48002
Tel: 82-51-519-3232

■ **Brazil – Autonics do Brasil Comercial Importadora Exportadora Ltda**
Tel: 55-11-2307-8480 / Fax: 55-11-2309-7784 / E-mail: comercial@autonics.com.br

■ **China – Autonics electronic(Jiaxing) Corporation**
Tel: 86-21-5422-5969 / Fax: 86-21-5422-5961 / E-mail: china@autonics.com

■ **India – Autonics Automation India Private Limited**
Tel: 91-22-2781-4305 / Fax: 91-22-2781-4518 / E-mail: india@autonics.com

■ **Indonesia – PT. Autonics Indonesia**
Tel: 62-21-8088-8814/5 / Fax: 62-21-8088-4442(4440) / E-mail: indonesia@autonics.com

■ **Japan – Autonics Japan Corporation**
Tel: 81-3-3950-3111 / Fax: 81-3-3950-3191 / E-mail: ja@autonics.com

■ **Malaysia – Mal-Autonics Sensor Sdn. Bhd.**
Tel: 60-3-7805-7190 / Fax: 60-3-7805-7193 / E-mail: malaysia@autonics.com

■ **Mexico – Autonics Mexico S.A. DE C.V**
Tel: 52-55-5207-0019 / Fax: 52-55-1663-0712 / E-mail: ventas@autonics.com

■ **Russia – Autonics Corp. Russia Representative Office**
Tel/Fax: 7-495-660-10-88 / E-mail: russia@autonics.com

■ **Turkey – Autonics Otomasyon Ticaret Ltd. Sti.**
Tel: 90-216-365-9117/3/4 / Fax: 90-216-365-9112 / E-mail: turkey@autonics.com

■ **USA – Autonics USA, Inc.**
Tel: 1-847-680-8160 / Fax: 1-847-680-8155 / E-mail: sales@autonicsusa.net

■ **Vietnam – Cong Ty TNHH Autonics Vina**
Tel: 84-8-3771-2662 / Fax: 84-8-3771-2663 / E-mail: vietnam@autonics.com