# Thru-beam sensor



# CE

## **Model Number**

## ML29-P/25/102/115

Thru-beam sensor with fixed cable

## **Features**

- Single-beam monitoring with extre-٠ mely narrow sensor
- Integrated circuit ٠
- Test •
- Simple installation Plug & Play
- Ideal for installation in door profiles or ٠ frames
- Light on version

# **Product information**

The narrow miniature thru-beam sensors are a small and cost-effective solution, fitting in virtually any door frame. The ML29 and ML30 series offer fast, reliable detection at a distance of up to 8.5 m. The sensors are easy to mount on the profile, either using adhesive strips or a screw. A large opening angle ensures problem-free alignment. Several sensors can be mounted in a cross formation to offer multi-beam protection.



## **Electrical connection**



### Indicators/operating means



Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001

Pepperl+Fuchs Group www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



be found at

Technical data			Typical applications
System components			Person detection for outematic dears and
Emitter		ML29-T/115	Person detection for automatic doors and     actes
Receiver		ML29-R/25/102/115	• Closing adda protection on sliding and
General specifications			Closing edge protection on sliding and     revelving doors
Effective detection range		0 6 m	Throughold manitoring for alguster dears
Threshold detection range		8.5 m	Stop monitoring for doors on public traps
Light source		IRED	<ul> <li>Step monitoring for doors on public trains- port vehicles</li> </ul>
Light type		modulated infrared light	Trigger function for rectarting escalators
Angle of divergence		+/- 8 °	• Thgger function for restarting escalators
Optical face		lateral	Detection and
Ambient light limit		40000 Lux	Detection area
Functional safety related par	ameters		
MTTF <sub>d</sub>		880 a	
Mission Time (T <sub>M</sub> )		20 a	
Diagnostic Coverage (DC)		0 %	
Indicators/operating means			
Function indicator		LED red in receiver : lights up when receiving the light beam	
Electrical apositiona			_
Operating voltage		11 30 \/ DC	
No lood ourply ourront	UB I	Fritter: < 25 mA	
No-load supply current	1 <sub>0</sub>	Receiver: ≤ 10 mA	
Input			
Test input		Test: Transmitter switches off at +UB $\leq$ 5 V DC	
Output			
Switching type		light on	
Signal output		1 NPN output, short-circuit protected, reverse polarity protected, open collector	
Switching voltage		max. 30 V DC	
Switching current		max. 0.1 A	
Switching frequency	f	100 Hz	
Response time		5 ms	Accessories
Ambient conditions			Accescines
Ambient temperature		-20 60 °C (-4 140 °F)	ML29 Front Plate Front plate for thru-beam sensors in se- ries ML29
Storage temperature		-20 75 °C (-4 167 °F)	
Relative humidity		90 %, noncondensing	
Mechanical specifications			
Degree of protection		IP65	Other suitable accessories can be found www.pepperl-fuchs.com
Connection		6 m fixed cable	
Material			
Housing		PMMA , black	
Optical face		Plastic pane	
Mass		per device 120 g	
Compliance with standards a	and directi	-	
Standard conformity			
Stanuard conformity			
Product standard		EN 00947-5-2:2007 IFC 60947-5-2:2007	
Standards		EN 61000-6-2 EN 61000-6-3	
Junurus			
Approvals and certificates			
CCC approval		CCC approval / marking not required for products rated ≤36 V	

CCC approval

# **Curves/Diagrams**



Release date: 2015-02-05 09:14 Date of issue: 2015-02-05 129309\_eng.xml

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



2



## **Function principle**

The thru-beam sensor requires a pair of devices for operation, comprising a light transmitter and a light receiver. The emitter and receiver must be arranged in optical alignment with each other. The infrared light from the emitter is detected by the receiver and evaluated.

## **Function**

#### Static detection:

The thru-beam sensor detects persons and objects independently of movement and surface structure for as long as the object breaks the detection beam.

		Electronic output
Light datastics /05	Person in the beam	Inactive
Light detection /25	No person in the beam	Active
Dark datastics /50	Person in the beam	Active
Dark delection /59	No person in the beam	Inactive

## **Optics:**

The relatively wide opening angles enable the light beam switches to be installed quickly, without alignment problems. Even if there is a light distortion of the installation profiles the function is retained.

## Testing:

Testing is used to check the function of the light beam switch.

With supply voltage +U<sub>B</sub> < 5 V the emitter device is switched off. This simulates a light beam interruption. By means of this, the function of the light barrier can be tested easily without using a separate test input.

#### Installation:

Thanks to its small dimensions, the light beam can be fitted in a U-profile or behind a face panel. The hole diameter for both the emitter and the receiver is 8 mm.

Even fixing by means of the adhesive tape contained in the delivery package can be considered.

#### Installation of twin-beam arrangement:



A twin-beam version requires 2 emitters and receivers. Care should be taken that the beam separation is not less than 20 cm. The transmitters and receivers must be arranged in the form of a cross.



Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



4