

CE

Model Number

ML29-P/25/102/143

Thru-beam sensor


4-pin plastic connector, 6.5 mm diameter

Features

- Single-beam monitoring with extre-• mely narrow sensor
- Integrated circuit ٠
- Test
- Simple installation Plug & Play
- Ideal for installation in door profiles or ٠ frames
- Light on version

Product information


The narrow miniature thru-beam sensors are a small and cost-effective solution, fitting in virtually any door frame. The ML29 and ML30 series offer fast, reliable detection at a distance of up to 8.5 m. The sensors are easy to mount on the profile, either using adhesive strips or a screw. A large opening angle ensures problem-free alignment. Several sensors can be mounted in a cross formation to offer multi-beam protection.



47

Electrical connection


Dimensions



Pinout



Indicators/operating means



1

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com


Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

PEPPERL+FUCHS

Technical data			Турі
System components			• Per
Emitter		ML29-T/143	gat
Receiver		ML29-R/25/102/143	Glo
General specifications			rev
Effective detection range		0 6 m	• Th
Threshold detection range		8.5 m	• Ste
Light source		IRED	por
Light type		modulated infrared light	• Tri
Angle of divergence		+/- 8 °	;
Optical face		lateral	Dete
Ambient light limit		40000 Lux	Dele
Functional safety related par	ameters		
MTTF _d		880 a	
Mission Time (T _M)		20 a	
Diagnostic Coverage (DC)		0 %	
Indicators/operating means			
Function indicator		LED red in receiver : lights up when receiving the light beam	
Electrical specifications			
Operating voltage	U _B	11 30 V DC	
No-load supply current	I ₀	Emitter: ≤ 25 mA	
	U	Receiver: ≤ 10 mA	-
Input			
Test input		Test: Transmitter switches off at +UB \leq 5 V DC	
Output			
Switching type		light on	
Signal output		1 NPN output, short-circuit protected, reverse polarity protected,	
		open collector	
Switching voltage		max. 30 V DC	
Switching current		max. 0.1 A	
Switching frequency	f	100 Hz	
Response time		5 ms	Acc
Ambient conditions			
Ambient temperature		-20 60 °C (-4 140 °F)	ML2
Storage temperature		-20 75 °C (-4 167 °F)	Fema
Relative humidity		90 % , noncondensing	serie
Mechanical specifications			
Degree of protection		IP65	ML29
Connection		4-pin plastic connector, 6.5 mm diameter	Front
Material			ries N
Housing		PMMA , black	
Optical face		Plastic pane	ML2
Mass		per device 120 g	Fema
Compliance with standards	and direct		serie
ves			Other
Standard conformity			
Product standard		EN 60947-5-2:2007	www.
Standards		IEC 60947-5-2:2007 EN 61000-6-2, EN 61000-6-3	
Glandarus		LIV 01000-0-2, LIV 01000-0-0	
Approvals and certificates			
CCC approval		CCC approval / marking not required for products rated \leq 36 V	

Curves/Diagrams



pplications

- etection for automatic doors and
- edge protection on sliding and doors
- d monitoring for elevator doors nitoring for doors on public transcles
- unction for restarting escalators

n area



ries

plungsdose 6m 4polig rdset with 6 m cable for ML29 sors

nt Plate

for thru-beam sensors in se-

plungsdose 3m 4polig

rdset with 3 m cable for ML29 sors

ble accessories can be found at rl-fuchs.com


Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Function principle

The thru-beam sensor requires a pair of devices for operation, comprising a light transmitter and a light receiver. The emitter and receiver must be arranged in optical alignment with each other. The infrared light from the emitter is detected by the receiver and evaluated.

Function

Static detection:

The thru-beam sensor detects persons and objects independently of movement and surface structure for as long as the object breaks the detection beam.

		Electronic output
Light datastion /05	Person in the beam	Inactive
Light detection /25	No person in the beam	Active
Dadada da anti-a a (FO	Person in the beam	Active
Dark detection /59	No person in the beam	Inactive

Optics:

The relatively wide opening angles enable the light beam switches to be installed quickly, without alignment problems. Even if there is a light distortion of the installation profiles the function is retained.

Testing:

Testing is used to check the function of the light beam switch.

With supply voltage +U_B < 5 V the emitter device is switched off. This simulates a light beam interruption. By means of this, the function of the light barrier can be tested easily without using a separate test input.

Installation:


Thanks to its small dimensions, the light beam can be fitted in a U-profile or behind a face panel. The hole diameter for both the emitter and the receiver is 8 mm.

Even fixing by means of the adhesive tape contained in the delivery package can be considered.

Installation of twin-beam arrangement:



A twin-beam version requires 2 emitters and receivers. Care should be taken that the beam separation is not less than 20 cm. The transmitters and receivers must be arranged in the form of a cross.





4