



# CE

# **Model Number**

#### ML30-P/25/102/115

Thru-beam sensor 6 m fixed cable


# **Features**

- Single-beam monitoring with extremely narrow sensor
- Integrated circuit
- Simple installation Plug & Play
- Ideal for installation in door profiles or
- Compact housing version with 2 mounting options


# **Product information**

The narrow miniature thru-beam sensors are a small and cost-effective solution, fitting in virtually any door frame. The ML29 and ML30 series offer fast, reliable detection at a distance of up to 8.5 m. The sensors are easy to mount on the profile, either using adhesive strips or a screw. A large opening angle ensures problem-free alignment. Several sensors can be mounted in a cross formation to offer multi-beam protection.

# **Dimensions**



### **Electrical connection**



- O = Light on
- = Dark on

# Indicators/operating means



Copyright Pepperl+Fuchs

Singapore: +65 6779 9091

fa-info@sg.pepperl-fuchs.com

1

# **Technical data**

#### System components

Emitter ML30-T/115 ML30-R/25/102/115

#### **General specifications**

Effective detection range 0 6 m Threshold detection range 8.5 m IRED Light source

Light type modulated infrared light

Angle of divergence +/- 8 ° Optical face lateral Ambient light limit 40000 Lux

#### Indicators/operating means

Function display LED red in receiver: lights up when receiving the light beam

#### **Electrical specifications**

Operating voltage 10 ... 32 V DC  $\mathsf{U}_\mathsf{B}$ No-load supply current Emitter: ≤ 25 mA  $I_0$ Receiver: ≤ 10 mA

#### Input

Test input Test: Transmitter switches off at +UB ≤ 5 V DC

#### Output

Switching type light on

Signal output 1 NPN output, short-circuit protected, reverse polarity protected,

open collector Switching voltage max. 30 V DC Switching current max. 0.1 A Switching frequency 100 Hz Response time

#### **Ambient conditions**

-20 ... 60 °C (-4 ... 140 °F) Ambient temperature Storage temperature -20 ... 75 °C (-4 ... 167 °F)

#### **Mechanical specifications**

Protection degree IP65 Connection 6 m fixed cable Material Housing PMMA, black

Optical face Plastic pane Mass per device 120 g

# Compliance with standards and directi-

ves

Standard conformity

Standards


Product standard EN 60947-5-2:2007 IEC 60947-5-2:2007

EN 61000-6-2, EN 61000-6-3

Approvals and certificates

CCC approval Products with a maximum operating voltage of ≤36 V do not bear a CCC marking because they do not require approval.

# **Curves/Diagrams**



# Typical allpications

- · Person detection for automatic doors and gates
- Closing edge protection on sliding and revolving doors
- Threshold monitoring for elevator doors
- Step monitoring for doors on public transport vehicles
- Trigger function for restarting escalators

### Sensing field



#### **Accessories**

#### **ML29 Front Plate**


Front plate for thru-beam sensors in series ML29

> Date of issue: 2012-06-21 207415\_eng.xml Release date: 2012-06-01 13:22

www.pepperl-fuchs.com

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091



# **Function principle**

The thru-beam sensor requires a pair of devices for operation, comprising a light transmitter and a light receiver. The emitter and receiver must be arranged in optical alignment with each other. The infrared light from the emitter is detected by the receiver and evaluated.

# **Function**

#### Static detection:

The thru-beam sensor detects persons and objects independently of movement and surface structure for as long as the object breaks the detection beam.

		Electronic output
Light detection /25	Person in the beam	Inactive
	No person in the beam	Active

### **Optics:**

The relatively wide opening angles enable the light beam switches to be installed quickly, without alignment problems. Even if there is a light distortion of the installation profiles the function is retained.

## Testing:

Testing is used to check the function of the thru-beam sensor.

fa-info@us.pepperl-fuchs.com

With supply voltage +U<sub>B</sub> < 5 V the emitter device is switched off. This simulates a light beam interruption. By means of this, the function of the light barrier can be tested easily without using a separate test input.

#### Installation:

Thanks to its small dimensions, the light beam can be fitted in a U-profile or behind a face panel. The hole diameter for both the emitter and the receiver is 4 mm.

Even fixing by means of the adhesive tape contained in the delivery package can be considered.

# Installation of twin-beam arrangement:

A twin-beam version requires 2 emitters and receivers. Care should be taken that the beam separation is not less than 20 cm. The transmitters and receivers must be arranged in the form of a cross.

