textheader





Model Number

OBE12M-R101-S2EP1-IO-V31

Thru-beam sensor with 4-pin, M8 x 1 connector

Features


- Miniature design with versatile • mounting options
- IO-link interface for service and ٠ process data
- Various frequencies for avoiding . mutual interference (cross-talk immunity)
- Extended temperature range • -40°C ... 60°C
- High degree of protection IP69K

Product information


The miniature optical sensors are the first devices of their kind to offer an end-to- end solution in a small single standard design — from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.


The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.



Electrical connection emitter



Electrical connection receiver



2 3 4

Pinout

 $^{2}_{1} \bigcirc ^{4}_{3}$

Wire colors in accordance with EN 60947-5-2 BN WH BU BK (brown (white) (blue) (black)

ena.xml

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com


Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com




Indicators/operating means

Emitter



Receiver



1 Operating indicator

1	Light-on/dark-on changeover switch
2	Sensitivity adjuster
3	Operating indicator / light on
4	Signal indicator
5	Operating indicator / dark on

Accessories

IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

OMH-R101

Mounting Clamp

OMH-R101-Front Mounting Clamp

OMH-4.1 Mounting Clamp

OMH-ML6 Mounting bracket

OMH-ML6-U Mounting bracket

OMH-ML6-Z

Mounting bracket

V31-GM-2M-PUR Female cordset, M8, 4-pin, PUR cable

V31-WM-2M-PUR Female cordset, M8, 4-pin, PUR cable

Other suitable accessories can be found at www.pepperl-fuchs.com

PEPPERL+FUCHS

www.pepperl-fuchs.com

Technical data		
System components		
Emitter		OBE12M-R101-S-IO-V31
Receiver		OBE12M-R101-2EP1-IO-V31
General specifications		
Effective detection range		0 12 m
Threshold detection range		15 m
Light source		LED
Light type		modulated visible red light
LED risk group labelling		exempt group
Diameter of the light spot		approx. 65 mm at a distance of 1 m
Angle of divergence		3.7°
Ambient light limit		EN 60947-5-2 : 30000 Lux
Functional safety related parame	ers	462 a
MTTF _d Mission Time (T _M)		462 a 20 a
Diagnostic Coverage (DC)		0%
Indicators/operating means		
Operation indicator		LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode
Function indicator		Yellow LED: Permanently lit - light path clear Permanently off - object detected Flashing (4 Hz) - insufficient operating reserve
Control elements		Receiver: light/dark switch
Control elements		Receiver: sensitivity adjustment
Parameterization indicator		IO link communication: green LED goes out briefly (1 Hz)
Electrical specifications		10 001/00
Operating voltage	UB	10 30 V DC max. 10 %
Ripple No-load supply current	I ₀	max. 10 % Emitter: ≤ 14 mA Receiver: ≤ 13 mA at 24 V supply voltage
Protection class		
Interface		
Interface type		IO-Link (via $C/Q = pin 4$)
Transfer rate		COM 2 (38.4 kBaud)
IO-Link Revision		1.1
Min. cycle time		2.3 ms
Process data witdh		Emitter: Process data output: 2 Bit Receiver: Process data input: 2 Bit Process data output: 2 Bit
SIO mode support		yes
Device ID		Emitter: 0x110401 (1115137) Receiver: 0x11030A (1114890)
Compatible master port type		Α
Input		
Test input		emitter deactivation at +U _B
Output		5
Switching type		The switching type of the sensor is adjustable. The default setting is: C/Q - Pin4: NPN normally closed / light-on, PNP normally open dark-on, IO-Link /Q - Pin2: NPN normally open / dark-on, PNP normally closed light-on
Signal output		2 push-pull (4 in 1)outputs, short-circuit protected, reverse polarity protected, overvoltage protected
Switching voltage		max. 30 V DC
Switching current		max. 100 mA, resistive load
Usage category		DC-12 and DC-13
Voltage drop Switching frequency	U _d f	≤ 1.5 V DC 1000 Hz
Switching frequency Response time	1	0.5 ms
Ambient conditions		
Amplent conditions		-40 60 °C (-40 140 °F)
Ambient temperature		-40 70 °C (-40 158 °F)
Storage temperature		
Storage temperature Mechanical specifications		18.3 mm
Storage temperature		
Storage temperature Mechanical specifications Housing width		18.3 mm
Storage temperature Mechanical specifications Housing width Housing height		18.3 mm 13.9 mm
Storage temperature Mechanical specifications Housing width Housing height Housing depth		18.3 mm 13.9 mm 33.8 mm
Storage temperature Mechanical specifications Housing width Housing height Housing depth Degree of protection		18.3 mm 13.9 mm 33.8 mm IP67 / IP69 / IP69K

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



textheader

Optical face

Mass


РММА
Emitter: approx. 10 g receiver: approx. 10 g


Directive conformity EMC Directive 2004/108/EC EN 60947-5-2:2007+A1:2012 Standard conformity EN 60947-5-2:2007+A1:2012 Product standard EN 60947-5-2:2007+A1:2012 Standards UL 60947-5-2:2007+A1:2012 Standards UL 60947-5-2:2001+A1:2012 Standards EN 61131-9:2013 EN 62471:2008 EN 61131-9:2013	Compliance with standards and directives	
Standard conformity EN 60947-5-2:2007+A1:2012 Product standard EN 60947-5-2:2007 + A1:2012 IEC 60947-5-2:2007 + A1:2012 IEC 60947-5-2:2014 Standards UL 60947-5-2: 2014 IEC 61131-9:2013 EN 62471:2008	Directive conformity	
Product standard EN 60947-5-2:2007+A1:2012 IEC 60947-5-2:2007 + A1:2012 Standards UL 60947-5-2: 2014 IEC 61131-9:2013 EN 62471:2008	EMC Directive 2004/108/EC	EN 60947-5-2:2007+A1:2012
IEC 60947-5-2:2007 + A1:2012 Standards UL 60947-5-2: 2014 IEC 61131-9:2013 EN 62471:2008	Standard conformity	
IEC 61131-9:2013 EN 62471:2008	Product standard	
	Standards	IEC 61131-9:2013 EN 62471:2008

Approvals and certificates UL approval


E87056, cULus Listed, class 2 power supply, type rating 1

Curves/Diagrams





Functions and Operation



- 1 Light-on / dark-on changeover switch
- 2 Sensing range /sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range adjuster for more than 180 degrees.

Sensing Range / Sensitivity

Turn sensing range / sensivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range /sensivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

4

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on / dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensivity adjustment is locked. In order to reactivate the sensing range /sensivity adjustment, turn the sensing range / sensivity adjuster for more than 180 degrees.

