

### **Model Number**

#### OBE20M-R101-S2EP-IO-V31-IR

**O**IO-Link

Thru-beam sensor with 4-pin, M8 x 1 connector

## **Features**

- Miniature design with versatile mounting options
- IO-link interface for service and process data
- Various frequencies for avoiding mutual interference (cross-talk immunity)
- Extended temperature range -40°C ... 60°C
- High degree of protection IP69K


# **Product information**

The miniature optical sensors are the first devices of their kind to offer an end-to- end solution in a small single standard design — from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.


The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.


## **Dimensions**



## **Electrical connection emitter**



### **Electrical connection receiver**



#### **Pinout**


Wire colors in accordance with EN 60947-5-2




3 E	VH (w BU (bl	own) hite) ue) ack)
4 E	BK (bl	ack)

# Indicators/operating means

# Emitter



### Receiver



- 1 Operating indicator
- 1 Light-on/dark-on changeover switch
- 2 Sensitivity adjuster
- 3 Operating indicator / light on
- 4 Signal indicator
- 5 Operating indicator / dark on

## **Accessories**

### IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

#### OMH-R101

Mounting Clamp

# OMH-R101-Front

Mounting Clamp

### OMH-4.1

Mounting Clamp

## OMH-ML6

Mounting bracket

### OMH-ML6-U

Mounting bracket

### OMH-ML6-Z

Mounting bracket

#### V31-GM-2M-PUR

Female cordset, M8, 4-pin, PUR cable

### V31-WM-2M-PUR

Female cordset, M8, 4-pin, PUR cable

Other suitable accessories can be found at www.pepperl-fuchs.com

Technical data		
System components		
Emitter		OBE20M-R101-S-IO-V31-IR
Receiver		OBE20M-R101-2EP-IO-V31-IR
General specifications		
Effective detection range		0.2 20 m
Threshold detection range		25 m
Light source		LED
Light type		modulated infrared light 850 nm
LED risk group labelling		exempt group
Diameter of the light spot		approx. 100 mm at a distance of 1 m
Angle of divergence		5.4 ° EN 60947-5-2 : 30000 Lux
Ambient light limit		EN 60947-5-2 : 30000 Lux
Functional safety related paran	ieters	462 a
MTTF <sub>d</sub> Mission Time (T <sub>M</sub> )		20 a
Diagnostic Coverage (DC)		0%
Indicators/operating means		0 /0
Operation indicator		LED green:
·		constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode
Function indicator		Yellow LED: Permanently lit - light path clear Permanently off - object detected Flashing (4 Hz) - insufficient operating reserve
Control elements		Receiver: light/dark switch
Control elements		Receiver: sensitivity adjustment
Parameterization indicator		IO link communication: green LED goes out briefly (1 Hz)
Electrical specifications		
Operating voltage	$U_B$	10 30 V DC
Ripple		max. 10 %
No-load supply current	I <sub>0</sub>	Emitter: ≤ 14 mA Receiver: ≤ 13 mA at 24 V supply voltage
Protection class		III
Interface		
Interface type		IO-Link ( via C/Q = pin 4 )
Transfer rate		COM 2 (38.4 kBaud)
IO-Link Revision		1.1
Min. cycle time		2.3 ms
Process data witdh		Emitter: Process data output: 2 Bit Receiver: Process data input: 2 Bit Process data output: 2 Bit
SIO mode support		yes
Device ID		Emitter: 0x110401 (1115137) Receiver: 0x110301 (1114881)
Compatible master port type		A
Input		
Test input		emitter deactivation at +U <sub>B</sub>
Output		
Switching type		The switching type of the sensor is adjustable. The default setting is:  C/Q - Pin4: NPN normally open / dark-on, PNP normally close light-on, IO-Link /Q - Pin2: NPN normally closed / light-on, PNP normally oper dark-on
Signal output		2 push-pull (4 in 1)outputs, short-circuit protected, reverse polarity protected, overvoltage protected
Switching voltage		max. 30 V DC
Switching current		max. 100 mA , resistive load
Usage category		DC-12 and DC-13
Voltage drop	U <sub>d</sub>	≤1.5 V DC
Switching frequency	f	1000 Hz
Response time		0.5 ms
Directive conformity		
Electromagnetic compatibility Directive 2014/30/EU		EN 60947-5-2/A1:2012
		LIN 00341-0-21A1.2012
Ambient conditions  Ambient temperature		-40 60 °C (-40 140 °F)
Storage temperature		-40 70 °C (-40 158 °F)
Mechanical specifications		
Housing width		18.3 mm
-		
Housing height		13.9 mm





Degree of protection	IP67 / IP69 / IP69K
Connection	M8 x 1 connector, 4-pin
Material	
Housing	PC (Polycarbonate)
Optical face	PMMA
Mass	Emitter: approx. 10 g receiver: approx. 10 g
Compliance with standards and directives	
Standard conformity	
Product standard	EN 60947-5-2:2007+A1:2012 IEC 60947-5-2:2007 + A1:2012
Standards	UL 60947-5-2: 2014 IEC 61131-9:2013 EN 62471:2008 EN 61131-9:2013
Approvals and certificates	

 $\mathsf{E87056}$  , cULus Listed , class 2 power supply , type rating 1


# **Curves/Diagrams**

**UL** approval





# **Functions and Operation**



- 1 Light-on / dark-on changeover switch
- 2 Sensing range /sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

Release date: 2018-12-17 14:03 Date of issue: 2018-12-17 291120\_eng.xml **EPPERL+FUCHS** 

To unlock the adjustment functions turn the sensing range adjuster for more than 180 degrees.

# **Sensing Range / Sensitivity**

Turn sensing range / sensivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range /sensivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

## **Light-on / Dark-on Configuration**

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on / dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

### **Restore Factory Settings**

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensivity adjustment is locked. In order to reactivate the sensing range / sensivity adjustment, turn the sensing range / sensivity adjuster for more than 180 degrees.