# Thru-beam sensor



CE 🚷 IO-Link

# **Model Number**

## OBE25M-R200-S2EP-IO-0,3M-V1

Thru-beam sensor with fixed cable

#### **Features**

- Medium design with versatile • mounting options
- IO-link interface for service and ٠ process data
- Various frequencies for avoiding • mutual interference (cross-talk immunity)
- Extended temperature range ٠ -40°C ... 60°C
- High degree of protection IP69K


## **Product information**

The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.


The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.


Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and can be adapted to the application environment.



# **Electrical connection emitter**



## **Electrical connection receiver**



2 3 4

#### **Pinout**



Wire colors in accordance with EN 60947-5-2 BN WH BU BK (brown (white) (blue) (black)

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group USA: +1 330 486 0001 www.pepperl-fuchs.com

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com




## Indicators/operating means

## Emitter

| Ē | - |
|---|---|
|   | Ц |
|   | 1 |
|   | 5 |
|   | ш |
|   |   |

Receiver



| 1 | Sensitivity adjustment               |  |
|---|--------------------------------------|--|
| 2 | Light-on / dark-on changeover switch |  |
| 3 | Operating indicator / dark on        |  |
| 4 | Signal indicator                     |  |
| 5 | Operating indicator / light on       |  |

Operating indicator

1

## Accessories

IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

Other suitable accessories can be found at www.pepperl-fuchs.com

2



| Technical data  |                     |   |
|---|---------------------|---|
| System components   |                     |   |
| Emitter   |                     | OBE25M-R200-S-IO-0,3M-V1  |
| Receiver  |                     | OBE25M-R200-2EP-IO-0,3M-V1  |
| General specifications  |                     |   |
| Effective detection range   |                     | 0 25 m  |
| Threshold detection range   |                     | 33 m  |
| Light source  |                     | LED   |
| Light type  |                     | modulated visible red light   |
| LED risk group labelling  |                     | exempt group  |
| Alignment aid   |                     | LED red (in receiver lens)<br>illuminated constantly: beam is interrupted,<br>flashes: reaching switching point,<br>off: sufficient stability control   |
| Diameter of the light spot  |                     | approx. 850 mm at a distance of 25 m  |
| Angle of divergence   |                     | approx. 2 °   |
| Ambient light limit   |                     | EN 60947-5-2 : 40000 Lux  |
| Functional safety related parame  | eters               | 400   |
| MTTF <sub>d</sub>   |                     | 462 a<br>20 a   |
| Mission Time (T <sub>M</sub> )<br>Diagnostic Coverage (DC)  |                     | 20 a<br>60 %  |
| <b>U U U U</b>  |                     | 00 %  |
| Indicators/operating means<br>Operation indicator   |                     | LED green:  |
| oporation indicator   |                     | constantly on - power on<br>flashing (4Hz) - short circuit<br>flashing with short break (1 Hz) - IO-Link mode   |
| Function indicator  |                     | Yellow LED:<br>Permanently lit - light path clear<br>Permanently off - object detected<br>Flashing (4 H2) - insufficient operating reserve  |
| Control elements  |                     | Receiver: light/dark switch   |
| Control elements  |                     | Receiver: sensitivity adjustment  |
| Electrical specifications   |                     |   |
| Operating voltage   | UB                  | 10 30 V DC  |
| Ripple  | 5                   | max. 10 %   |
| No-load supply current  | I <sub>0</sub>      | Emitter: $\leq$ 15 mA<br>Receiver: $\leq$ 15 mA at 24 V Operating voltage   |
| Protection class  |                     | III   |
| Interface   |                     |   |
| Interface type  |                     | IO-Link ( via C/Q = pin 4 )   |
| Device profile  |                     | Identification and diagnosis<br>Smart Sensor:<br>Receiver: type 2.4<br>Emitter: -   |
| Transfer rate   |                     | COM 2 (38.4 kBaud)  |
| IO-Link Revision  |                     | 1.1   |
| Min. cycle time   |                     | 2.3 ms  |
| Process data witdh  |                     | Emitter:<br>Process data input: 0 bit<br>Process data output: 1 bit<br>Receiver:<br>Process data input: 2 bit<br>Process data output: 2 bit   |
| SIO mode support  |                     | yes   |
| Device ID   |                     | Emitter: 0x111401 (1119233)<br>Receiver: 0x111301 (1118977)   |
| Compatible master port type   |                     | A   |
| Input   |                     |   |
| Test input  |                     | emitter deactivation at +U <sub>B</sub>   |
| Output  |                     |   |
| Switching type  |                     | The switching type of the sensor is adjustable. The default setting is:<br>C/Q - Pin4: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link<br>/Q - Pin2: NPN normally closed / light-on, PNP normally open / dark-on |
|   |                     | 2 push-pull (4 in 1)outputs, short-circuit protected, reverse<br>polarity protected, overvoltage protected  |
| Signal output   |                     | polarity protected, overvoltage protected   |
| Signal output<br>Switching voltage  |                     | max. 30 V DC  |
| Switching voltage<br>Switching current  |                     | max. 30 V DC<br>max. 100 mA , resistive load  |
| Switching voltage<br>Switching current<br>Usage category  |                     | max. 30 V DC<br>max. 100 mA , resistive load<br>DC-12 and DC-13   |
| Switching voltage<br>Switching current<br>Usage category<br>Voltage drop  | U <sub>d</sub>      | max. 30 V DC<br>max. 100 mA , resistive load<br>DC-12 and DC-13<br>≤ 1.5 V DC   |
| Switching voltage<br>Switching current<br>Usage category<br>Voltage drop<br>Switching frequency                                       | U <sub>d</sub><br>f | max. 30 V DC<br>max. 100 mA , resistive load<br>DC-12 and DC-13<br>≤ 1.5 V DC<br>1000 Hz  |
| Switching voltage<br>Switching current<br>Usage category<br>Voltage drop<br>Switching frequency<br>Response time                      | <b>u</b>            | max. 30 V DC<br>max. 100 mA , resistive load<br>DC-12 and DC-13<br>≤ 1.5 V DC   |
| Switching voltage<br>Switching current<br>Usage category<br>Voltage drop<br>Switching frequency<br>Response time<br><b>Conformity</b> | <b>u</b>            | max. 30 V DC<br>max. 100 mA, resistive load<br>DC-12 and DC-13<br>≤ 1.5 V DC<br>1000 Hz<br>0.5 ms   |
| Switching voltage<br>Switching current<br>Usage category<br>Voltage drop<br>Switching frequency<br>Response time                      | <b>u</b>            | max. 30 V DC<br>max. 100 mA , resistive load<br>DC-12 and DC-13<br>≤ 1.5 V DC<br>1000 Hz  |

Refer to "General Notes Relating to Pepperl+Fuchs Product Information". Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com





| Ambient temperature       | -40 60 °C (-40 140 °F) , fixed cable -20 60 °C (-4 140 °F) , movable cable not appropriate for conveyor chains |
|---------------------------|--|
| Storage temperature       | -40 70 °C (-40 158 °F)   |
| Mechanical specifications |  |
| Housing width             | 15 mm  |
| Housing height            | 50.6 mm  |
| Housing depth             | 41.7 mm  |
| Degree of protection      | IP67 / IP69 / IP69K  |
| Connection                | 300 mm fixed cable with M12 x 1, 4-pin connector   |
| Material                  |  |
| Housing                   | PC (Polycarbonate)   |
| Optical face              | PMMA   |
| Mass                      | Emitter: approx. 45 g receiver: approx. 45 g   |
| Cable length              | 0.3 m  |
|                           |  |

#### Approvals and certificates

UL approval CCC approval E87056 , cULus Listed , class 2 power supply , type rating 1 CCC approval / marking not required for products rated  ${\leq}36~V$ 

#### **Curves/Diagrams**





#### **Functions and Operation**

To unlock the adjustment functions turn the sensing range /sensitivity adjuster for more than 180 degrees.

## Sensing Range / Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

## Light-on / Dark-on Configuration

4

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.



If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

#### **Restore Factory Settings**

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range /sensitivity adjuster for more than 180 degrees.

