

# **Model Number**

# OBE40M-R200-SEP-IO-0,3M-V3-L

Laser thru-beam sensor with fixed cable

## **Features**

- Medium design with versatile • mounting options
- DuraBeam Laser Sensors durable ٠ and employable like an LED
- IO-link interface for service and • process data
- Various frequencies for avoiding mutual interference (cross-talk immunity)
- Extended temperature range -40°C ... 60°C
- High degree of protection IP69K

# **Product information**


The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.


The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and


can be adapted to the application environment.



# **Electrical connection emitter**



# **Electrical connection receiver**



3

## **Pinout**



Wire colors in accordance with EN 60947-5-2 BN BU BK (brown) (blue) (black)

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Emitter

Receiver

敫

# Indicators/operating means Laserlabel Operating indicator 1 CLASS 1 I ASER PRODUCT ГШ CLASS 1 LASER PRODUCT IEC 60825-1: 2007 certified. Complies with 21 CFR 1040.10 and 1040.11 except 1 Sensitivity adjustment for deviations pursuant to Laser Notice No. 50, dated June 24, 2007 2 Light-on / dark-on changeover switch Ē 3 Operating indicator / dark on O 4 Signal indicator Ш 5 Operating indicator / light on CLASS 1 LASER PRODUCT IEC 60825-1: 2007 certified. Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007 **Accessories** IO-Link-Master02-USB IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection V3-GM-2M-PUR Cable socket, M8, 3-pin, PUR cable V3-WM-2M-PUR Cable socket, M8, 3-pin, PUR cable Other suitable accessories can be found at www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



2

www.pepperl-fuchs.com

Technical data		
System components		
Emitter		OBE40M-R200-S-IO-0,3M-V3-L
Beceiver		OBE40M-R200-EP-IO-0,3M-V3-L
General specifications		
•		0 40 m
Effective detection range		50 m
Threshold detection range		laser diode
Light source		
Light type		modulated visible red light
Laser nominal ratings Note		
		LASER LIGHT , DO NOT STARE INTO BEAM
Laser class		1
Wave length		680 nm
Beam divergence		> 5 mrad ; d63 < 2 mm in the range of 250 mm 750 mm
Pulse length		1.6 µs
Repetition rate		max. 17.6 kHz
max. pulse energy		9.6 nJ
Alignment aid		LED red (in receiver lens) illuminated constantly: beam is interrupted, flashes: reaching switching point, off: sufficient stability control
Diameter of the light spot		approx. 80 mm at a distance of 40 m
Angle of divergence		approx. 0.12 °
Ambient light limit		EN 60947-5-2 : 40000 Lux
Functional safety related parame	eters	
MTTF <sub>d</sub>		440 a
Mission Time (T <sub>M</sub> )		20 a
Diagnostic Coverage (DC)		60 %
Indicators/operating means		
Operation indicator		LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode
Function indicator		Yellow LED: Permanently lit - light path clear Permanently off - object detected Flashing (4 Hz) - insufficient operating reserve
Control elements		Receiver: light/dark switch
Control elements		Receiver: sensitivity adjustment
Electrical specifications		
		10 001/100
Operating voltage	UB	10 30 V DC max. 10 %
Ripple No-load supply current	I <sub>0</sub>	Emitter: < 13 mA Receiver: < 15 mA at 24 V Operating voltage
Protection class		Heceiver. ≤ 15 mA at 24 v Operating voltage
Interface		
Interface type		IO-Link (via C/Q = pin 4)
Device profile		Identification and diagnosis Smart Sensor: Receiver: type 2.4 Emitter: -
Transfor rate		
Transfer rate IO-Link Revision		COM 2 (38.4 kBaud) 1.1
Min. cycle time		2.3 ms
Process data witdh		Emitter: Process data input: 0 bit Process data output: 1 bit Receiver: Process data input: 2 bit Process data output: 2 bit
SIO mode support		Yes
Device ID		Emitter: 0x111402 (1119234)
Compatible master port type		Receiver: 0x111302 (1118978) A
Input		
Test input		emitter deactivation at +U <sub>B</sub>
Output		
Switching type		The switching type of the sensor is adjustable. The default setting is: C/Q - Pin4: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link
Of a second seco		1 push-pull (4 in 1) output, short-circuit protected, reverse polarity protected, overvoltage protected
Signal output		
Switching voltage		max. 30 V DC
Switching voltage Switching current		max. 100 mA , resistive load
Switching voltage Switching current Usage category		max. 100 mA , resistive load DC-12 and DC-13
Switching voltage Switching current Usage category Voltage drop	U <sub>d</sub>	max. 100 mA , resistive load DC-12 and DC-13 ≤ 1.5 V DC
Switching voltage Switching current Usage category	U <sub>d</sub> f	max. 100 mA , resistive load DC-12 and DC-13

Pepperl+Fuchs Group USA: +1 330 486 0001 www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



#### Conformity

Communication interface Product standard Laser safety

Ambient conditions Ambient temperature

#### Storage temperature

-40 ... 70 °C (-40 ... 158 °F) **Mechanical specifications** Housing width 15 mm Housing height 50.6 mm Housing depth 41.7 mm Degree of protection IP67 / IP69 / IP69K 300 mm fixed cable with M8 x 1, 3-pin connector Connection Material Housing PC (Polycarbonate) Optical face PMMA Emitter: approx. 41 g receiver: approx. 41 g Mass Cable length 0.3 m

IEC 61131-9

EN 60947-5-2

EN 60825-1:2014

conveyor chains

-40 ... 60 °C (-40 ... 140 °F) , fixed cable

-20 ... 60 °C (-4 ... 140 °F) , movable cable not appropriate for


#### Approvals and certificates


UL approval CCC approval

FDA approval

E87056 , cULus Listed , class 2 power supply , type rating 1 CCC approval / marking not required for products rated ≤36 V IEC 60825-1:2007 Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007

## **Curves/Diagrams**





### **Functions and Operation**

To unlock the adjustment functions turn the sensing range /sensitivity adjuster for more than 180 degrees.

4



# Sensing Range / Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

# Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

## **Restore Factory Settings**

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range /sensitivity adjuster for more than 180 degrees.

