







# **Model Number**


# OBE500-R2F-SE2-0,2MV31-Y263382

Thru-beam sensor (pair) with 0.2 m fixed cable and M8 plug, 4-pin


### **Features**


- Very flat design for direct mounting without mounting bracket
- TEACH-IN
- Detection of partially transparent objects by teach-in
- Very bright, highly visible light spot

# **Dimensions**



# **Electrical connection**





# **Pinout**

Wire colors in accordance with EN 60947-5-2



1	BN	(browi
2	WH	(white
3	BU	(blue)
4	BK	(black

Technical data			
System components			
Emitter		OBE500-R2F-S-0,2M-V31	
Receiver		OBE500-R2F-E2-0,2M-V31-Y814590	
General specifications			
Effective detection range		0 500 mm	
Threshold detection range		700 mm	
Light source		LED	
Light type		modulated visible red light, 630 nm	
LED risk group labelling		exempt group	
Angle deviation		approx. 2 °	
Object size		typ. starts from 1.5 mm	
Diameter of the light spot		approx. 60 mm at a distance of 500 mm	
Angle of divergence		approx. 5 °	
Optical face		frontal	
Ambient light limit		EN 60947-5-2 : 25000 Lux	
Functional safety related paramet	ers		
MTTF <sub>d</sub>		806 a	
Mission Time (T <sub>M</sub> )		20 a	
Diagnostic Coverage (DC)		0 %	
Indicators/operating means			
Operation indicator		LED green, statically lit Power on , short-circuit : LED green flashing (approx. 4 Hz)	
Function indicator		Receiver: LED yellow, lights up when light beam is free, flashes when falling short of the stability control; OFF when light beam is interrupted	
Electrical specifications			
Operating voltage	U <sub>B</sub>	10 30 V DC	
No-load supply current	I <sub>0</sub>	< 10 mA	
Protection class		III	
Input			
Test input		Test of switching function at 0 V	
Switching threshold		Teach-In input	
Output			
Switching type		NO contact / dark on	
Signal output		1 PNP output, short-circuit protected, reverse polarity protected open collector	
Switching voltage		max. 30 V DC	
Switching current		max. 50 mA , resistive load	
- ·	U <sub>d</sub>	≤ 1.5 V DC	
3 - 1 7	f	approx. 1 kHz	
Response time		500 μs	
Directive conformity			
Electromagnetic compatibility			
Directive 2014/30/EU		EN 60947-5-2:2007 EN 60947-5-2/A1:2012	
Standard conformity			
Standards		EN 60947-5-2:2007 EN 60947-5-2/A1:2012 EN 62471:2008 UL 60947-5-2: 2014	
Ambient conditions			
Ambient temperature		-20 60 °C (-4 140 °F)	
Storage temperature		-20 70 °C (-4 158 °F)	
Mechanical specifications			
Housing width		12 mm	
Housing height		25.5 mm	
Housing depth		4.1 mm	
Degree of protection		IP67	
Connection		200 mm fixed cable with 4-pin, M8x1 connector	
Material			
Housing		PC (Polycarbonate) and Stainless steel	
Optical face		PMMA	
Cable		PUR	
Mass		approx. 10 g Per sensor	
Tightening torque, fastening screws		0.25 Nm	
Cable length		200 mm	
Approvals and cortificates			
Approvals and certificates		E970E6 al II un Bonognizad Class C Bourse Course	
UL approval		E87056, cULus Recognized, Class 2 Power Source	
CCC approval		CCC approval / marking not required for products rated ≤36 V	

# Accessories

### V31-GM-2M-PUR


Female cordset, M8, 4-pin, PUR cable


### V31-WM-2M-PUR

Female cordset, M8, 4-pin, PUR cable

Other suitable accessories can be found at www.pepperl-fuchs.com

# Characteristic response curve Offset Y [mm] 150 100 50 -150 0 200 400 600 800 1000 1200 1400 1600 1800 2000 Distance X [mm]





### **Teach-In Methods**


The thru-beam sensor enables the switching points to be taught in for optimum adaptation to specific applications. This eliminates the need for additional components such as apertures.

The sensitivity of the thru-beam sensor can be adjusted using three Teach-in methods:

### **Position Teach**

When using this Teach-in method, the following settings are made on the thru-beam sensor:

- The gain is set to an optimum value
- The signal threshold is set to a minimum



### Recommended application:

This method enables minuscule particles in the beam path to be detected, and provides exceptional positioning accuracy.


Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.


- Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash simultaneously at 2.5 Hz
- Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash alternately at 2.5 Hz
- The end of the Teach-in process is indicated when the green LED indicator lights up static and yellow LED blinks.

### **Two-Point Teach-In**

When using this Teach-in method, the following settings are made on the thru-beam sensor:

- · The gain is set to an optimum value
- · The signal threshold is set in the center between the two taught signal values







- Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.
- Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash simultaneously at 2.5 Hz
- Position the object in the beam path.
- Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash alternately at 2.5 Hz
- The end of the Teach-in process is indicated when the green LED indicator lights up static.

### **Maximum Teach-In**

When using this Teach-in method, the following settings are made on the thru-beam sensor:

- The gain is set to a maximum
- The signal threshold is set to a minimum





### Recommended application:

Enables an object to be detected with a high excess gain. This can be useful if there is severe environmental contamination or to achieve long operating times.

Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.

- Cover the receiver or transmitter.
- Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash simultaneously at 2.5 Hz
- Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash alternately at 2.5 Hz
- The end of the Teach-in process is indicated when the green LED indicator lights up static.