

CE 🚷 IO-Link C US

Model Number

OBR15M-R200-2EP-IO-0,3M-V15

Retroreflective sensor with polarization filter

with fixed cable and M12 connector, 5-pin

Features

- ٠ Medium design with versatile mounting options
- Extended temperature range -40°C ... 60°C
- ٠ High degree of protection IP69K
- IO-link interface for service and • process data

Product information


The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and

can be adapted to the application environment.



Electrical connection




Pinout



Wire colors in accordance with EN 60947-5-2 BN (brown) (white) (blue) (black) BIN WH BU BK GY (grav)

2345

Indicators/operating means



1	Sensitivity adjustment		
2	2 Light-on / dark-on changeover switch		
3	Operating indicator / dark on		
4	Signal indicator		
5	Operating indicator / light on	GN	

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Reflector, rectangular 51 mm x 61 mm,

Reflector, rectangular 60 mm x 19 mm,

IO-Link master, supply via USB port or

separate power supply, LED indicators,

Female cordset, M12, 5-pin, PUR cable

Female cordset, M12, 5-pin, PUR cable

Other suitable accessories can be found at

Reflector, rectangular 84.5 mm x

84.5 mm, mounting holes

www.pepperl-fuchs.com

Reflective tape 100 mm x 100 mm

M12 plug for sensor connection

Reflector, round ø 84 mm, central

IO-Link-Master02-USB

mounting holes, fixing strap

Accessories

REF-H50

RFF-VR10

mounting holes

OFR-100/100

REF-C110-2

mounting hole

V15-W-2M-PUR

V15-G-2M-PUR

REF-H85-2

Technical data

General specifications Effective detection range Reflector distance Threshold detection range Reference target Light source Light type LED risk group labelling Polarization filter Diameter of the light spot Angle of divergence Ambient light limit Functional safety related parameters MTTF_d

Diagnostic Coverage (DC) Indicators/operating means Operation indicator

Function indicator

Mission Time (T_M)

Control elements Control elements

Electrical specifications Operating voltage

Ripple No-load supply current Protection class

Interface Interface type Device profile

Transfer rate **IO-Link Revision** Min. cycle time Process data witdh

SIO mode support Device ID Compatible master port type Input

Test input

Output Switching type

Signal output

Switching voltage Switching current

Usage category Voltage drop

Switching frequency Response time Conformity

Communication interface Product standard

Ambient conditions Ambient temperature

Storage temperature **Mechanical specifications** Housing width Housing height Housing depth Degree of protection

0...15 m 0.02 ... 15 m 18.5 m H85-2 reflector I FD modulated visible red light exempt group ves approx. 520 mm at a distance of 15 m 2 EN 60947-5-2 : 60000 Lux

724 a 20 a 60 %

UB

 I_0

 U_{d}

LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode Yellow LED: Permanently lit - light path clear Permanently off - object detected Flashing (4 Hz) - insufficient operating reserve Light-on/dark-on changeover switch sensitivity adjustment

10 30 V DC max. 10 % < 18 mA at 24 V Operating voltage

IO-Link (via C/Q = pin 4) Identification and diagnosis Smart Sensor type 2.4 COM 2 (38.4 kBaud) 1.1 2.3 ms Process data input 2 Bit Process data output 2 Bit yes 0x111203 (1118723) emitter deactivation at +U_B The switching type of the sensor is adjustable. The default setting is: C/Q - Pin4: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link /Q - Pin2: NPN normally closed / light-on, PNP normally open / dark-on

2 push-pull (4 in 1)outputs, short-circuit protected, reverse polarity protected, overvoltage protected max. 30 V DC max. 100 mA, resistive load DC-12 and DC-13 $\leq 1.5 \text{ V DC}$ 1000 Hz 0.5 ms IEC 61131-9 EN 60947-5-2 -40 ... 60 °C (-40 ... 140 °F) , fixed cable -20 ... 60 °C (-4 ... 140 °F) , movable cable not appropriate for conveyor chains -40 ... 70 °C (-40 ... 158 °F) 15 mm 50.6 mm

300 mm fixed cable with plug, M12 x 1, 5 pin



Release date: 2018-05-22 17:12

Date of issue: 2018-09-19 295670-100015_eng.xml

Connection

Material

2

fa-info@us.pepperl-fuchs.com

41.7 mm

IP67 / IP69 / IP69K


fa-info@de.pepperl-fuchs.com


Housing Optical face Mass Cable length PC (Polycarbonate) PMMA approx. 45 g 0.3 m

Approvals and certificates

UL approval CCC approval E87056 , cULus Listed , class 2 power supply , type rating 1 CCC approval / marking not required for products rated \leq 36 V

Curves/Diagrams





Functions and Operation

To unlock the adjustment functions turn the sensing range /sensitivity adjuster for more than 180 degrees.

Sensing Range / Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range / sensitivity adjuster for more than 180 degrees.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".							
Pepperl+Fuchs Group	USA: +1 330 486 0001	Germany: +49 621 776 4411	Singapore: +65 6779 9091				
www.pepperl-fuchs.com	fa-info@us.pepperl-fuchs.com	fa-info@de.pepperl-fuchs.com	fa-info@sg.pepperl-fuchs.com				

3

F

P

W

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



4