

Model Number

OBR15M-R201-EP-IO-0,3M-V3

Retroreflective sensor

with fixed cable and 3-pin, M8 connector

Features

- Medium design with versatile • mounting options
- Extended temperature range ٠ -40°C ... 60°C
- High degree of protection IP69K .
- IO-link interface for service and • process data

Product information


The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.


The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and

can be adapted to the application environment.





3 4

Electrical connection




Dimensions

Pinout

Wire colors in accordance with EN 60947-5-2 (brown) (blue) (black) ΒN BU BK

Indicators/operating means



	1	Sensitivity adjustment	
	2	Light-on / dark-on changeover switch	
	3	Operating indicator / dark on	GN
	4	Signal indicator	YE
ſ	5	Operating indicator / light on	GN

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



 U_B

 I_0

Ud

Technical data General specifications Effective detection range

Reflector distance

Light type

MTTF_d Mission Time (T_M)

Threshold detection range Reference target Light source

LED risk group labelling Polarization filter Diameter of the light spot

Angle of divergence Ambient light limit

Diagnostic Coverage (DC)

Indicators/operating means

Operation indicator

Function indicator

Control elements

Control elements **Electrical specifications**

Operating voltage

Protection class Interface Interface type Device profile Transfer rate **IO-Link Revision** Min. cycle time Process data witdh SIO mode support Device ID

No-load supply current

Compatible master port type

Ripple

Output Switching type

Signal output Switching voltage Switching current

Usage category

Communication interface Product standard Ambient conditions Ambient temperature

Storage temperature **Mechanical specifications** Housing width Housing height Housing depth Degree of protection Connection

Material Housing

Mass

Optical face

Cable length

Voltage drop Switching frequency Response time Conformity

Functional safety related parameters

OBR15M-R201-EP-IO-0,3M-V3

	Accessories
	Accessories
0 15 m	REF-H50
0.02 15 m	Reflector, rectangular 51 mm x 61 mm,
18.5 m	mounting holes, fixing strap
H85-2 reflector	REF-VR10
LED	
modulated visible red light	Reflector, rectangular 60 mm x 19 mm,
exempt group	mounting holes
yes	OFR-100/100
approx. 520 mm at a distance of 15 m	Reflective tape 100 mm x 100 mm
2 °	
EN 60947-5-2 : 60000 Lux	V3-WM-2M-PUR Cable socket, M8, 3-pin, PUR cable
724 a	IO-Link-Master02-USB
20 a	
0 %	IO-Link master, supply via USB port or
	separate power supply, LED indicators,
LED green:	M12 plug for sensor connection
constantly on - power on	REF-C110-2
flashing (4Hz) - short circuit	
flashing with short break (1 Hz) - IO-Link mode Yellow LED:	Reflector, round ø 84 mm, central
Permanently lit - light path clear	mounting hole
Permanently off - object detected	REF-H85-2
Flashing (4 Hz) - insufficient operating reserve	
Light-on/dark-on changeover switch	Reflector, rectangular 84.5 mm x
sensitivity adjustment	84.5 mm, mounting holes
	Other suitable accessories can be found at
10 30 V DC	www.pepperl-fuchs.com
max. 10 %	
< 18 mA at 24 V Operating voltage	
III	
IO-Link (via C/Q = pin 4)	
Identification and diagnosis	
Smart Sensor type 2.4	
COM 2 (38.4 kBaud)	
1.1	
2.3 ms Process data input 2 Bit	
Process data input 2 Bit	
yes	
0x111211 (1118737)	
A	
The switching type of the sensor is adjustable. The default	
setting is:	
C/Q - Pin4: NPN normally open / dark-on, PNP normally closed /	
light-on, IO-Link	
1 push-pull (4 in 1) output, short-circuit protected, reverse polarity protected, overvoltage protected	
max. 30 V DC	
max. 100 mA , resistive load	
DC-12 and DC-13	
≤ 1.5 V DC	
1000 Hz	
0.5 ms	
IEC 61131-9	
EN 60947-5-2	
	9
-40 60 °C (-40 140 °F) , fixed cable	
-20 60 °C (-4 140 °F) , movable cable not appropriate for	
conveyor chains	
-40 70 °C (-40 158 °F)	
	-
15 mm	
61.7 mm	
41.7 mm	
IP67 / IP69 / IP69K	

Release date: 2018-05-23 09:22 Date of issue: 2018-09-19 295670-100061_eng.xml

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

PMMA

0.3 m

approx. 51 g

PC (Polycarbonate)

300 mm fixed cable with M8 x 1, 3-pin connector

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



2


Approvals and certificates




CCC approval

E87056, cULus Listed, class 2 power supply, type rating 1 CCC approval / marking not required for products rated ≤36 V

Curves/Diagrams





Functions and Operation

To unlock the adjustment functions turn the sensing range /sensitivity adjuster for more than 180 degrees.

Sensing Range / Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range /sensitivity adjuster for more than 180 degrees.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

