

CE **OIO**-Link

Model Number

OBT300-R103-2EP-IO-0,3M-V31-1T

Triangulation sensor (BGE) with fixed cable and 4-pin, M8 connector

Features

- Miniature design with versatile • mounting options
- Secure and gapless detection, even ٠ near the surface through background evaluation
- Precision object detection, almost ٠ irrespective of the color
- Extended temperature range -40°C ... 60°C
- High degree of protection IP69K
- IO-link interface for service and process data


Product information

The R103 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design - from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.


The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.




Electrical connection



Pinout



Indicators/operating means



1	Light-on/dark-on changeover switch
2	Sensing range adjuster
3	Operating indicator / dark on
4	Function indicator
5	Operating indicator / light on

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Technical data General specifications Detection range Detection range min. F Detection range max. F Adjustment range Reference target Light source Light type LED risk group labelling Black/White difference (6 %/90 %) Diameter of the light spot Angle of divergence a Ambient light limit F Functional safety related parameters Mission Time (T_M) 20 a Diagnostic Coverage (DC) Indicators/operating means Operation indicator Function indicator Control elements Control elements **Electrical specifications** Operating voltage U_B Ripple No-load supply current I_0 Protection class Interface Interface type Device profile Transfer rate **IO-Link Revision** Min. cycle time Process data witdh SIO mode support Device ID Compatible master port type Output Switching type Signal output Switching voltage Switching current Usage category Ud Voltage drop Switching frequency Response time Conformity Communication interface Product standard Ambient conditions Ambient temperature Storage temperature **Mechanical specifications** Housing width Housing height Housing depth Degree of protection Connection Material

5 300 mm
5 25 mm
5 300 mm
25 300 mm
standard white, 100 mm x 100 mm
LED
modulated visible red light
exempt group
< 15 % at 300 mm
approx. 18 mm at a distance of 300 mm
approx. 3 °
EN 60947-5-2 : 40000 Lux

20 4
0 %
LED green:
constantly on - power on
flashing (4Hz) - short circuit
flashing with short break (1 Hz) - IO-Link mode
LED yellow:
constantly on - background detected (object not detected)
constantly off - object detected
Light-on/dark-on changeover switch
Sensing range adjuster
10 30 V DC
max. 10 %
< 25 mA at 24 V supply voltage
III
IO-Link (via C/Q = pin 4)
Smart Sensor
COM 2 (38.4 kBaud)
1.1
2.3 ms
Process data input 1 Bit
Process data output 2 Bit
yes
0x110704 (1115908)
Α
n
The switching type of the sensor is adjustable. The default
setting is:
C/Q - BK: NPN normally open / dark-on, PNP normally closed /
light-on, IO-Link
/Q - WH: NPN normally closed / light-on, PNP normally open /
dark-on
2 push-pull (4 in 1)outputs, short-circuit protected, reverse
polarity protected, overvoltage protected
max. 30 V DC
max. 100 mA , resistive load
DC-12 and DC-13
≤ 1.5 V DC
500 Hz
1 ms
IEC 61131-9
EN 60947-5-2
~_
-40 60 °C (-40 140 °F) , fixed cable
-25 60 °C (-13 140 °F) , movable cable not appropriate for
conveyor chains
-40 70 °C (-40 158 °F)
15 mm
36.5 mm
26.7 mm
IP67 / IP69 / IP69K
fixed cable 300 mm with M8 x 1 male connector; 4-pin
PC (Polycarbonate)
PMMA
approx. 17 g
0.3 m

Accessories

IO-Link-Master02-USB IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

OMH-R103-01 Mounting bracket

V31-GM-2M-PUR Female cordset, M8, 4-pin, PUR cable

V31-WM-2M-PUR Female cordset, M8, 4-pin, PUR cable

OMH-R101-Front Mounting Clamp

OMH-R101 Mounting Clamp

OMH-4.1 Mounting Clamp

OMH-ML6 Mounting bracket

OMH-ML6-U Mounting bracket

OMH-ML6-Z Mounting bracket

Other suitable accessories can be found at www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com




Housing Optical face Mass Cable length


Approvals and certificates


UL approval

E87056, cULus Listed, class 2 power supply, type rating 1

Curves/Diagrams








Release date: 2018-06-08 14:39 Date of issue: 2018-06-08 267075-100270_eng.xml


Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group USA: +1 330 486 0001

fa-info@us.pepperl-fuchs.com





Functions and Operation



- 1 Light-on / dark-on changeover switch
- 2 Sensing range / sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range adjuster / sensitivity adjuster for more than 180 degrees.

Sensing Range/ Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range / sensitivity adjuster for more than 180 degrees.

PEPPERL+FUCHS