

CE 🚷 IO-Link

Model Number

OBT300-R200-2EP-IO-V1-1T

Triangulation sensor (BGE) with 4-pin, M12 x 1 connector

Features

- Medium design with versatile • mounting options
- Secure and gapless detection, even ٠ near the surface through background evaluation
- Precision object detection, almost ٠ irrespective of the color
- Extended temperature range -40°C ... 60°C
- High degree of protection IP69K
- IO-link interface for service and • process data

Product information


The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and

can be adapted to the application environment.



Electrical connection




Pinout





Indicators/operating means



1	Sensitivity adjustment	
2	Light-on / dark-on changeover switch	
3	Operating indicator / dark on	GN
4	Signal indicator	YE
5	Operating indicator / light on	GN

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Technical data		
General specifications		
Detection range		30 300 mm
Detection range min.		30 80 mm
Detection range max.		30 300 mm
Adjustment range		80 300 mm
Reference target		standard white, 100 mm x 100 mm
Light source		LED
Light type		modulated visible red light
LED risk group labelling		exempt group
Black/White difference (6 %/90 %)	< 5 % at 300 mm
Diameter of the light spot	,	approx. 8 mm x 8 mm at a distance of 300 mm
Angle of divergence		approx. 1.5 °
Ambient light limit		EN 60947-5-2 : 70000 Lux
<u> </u>		EN 00347-3-2 : 70000 Eux
Functional safety related param	eters	600 -
MTTF _d		600 a
Mission Time (T _M)		20 a
Diagnostic Coverage (DC)		0 %
ndicators/operating means		
Operation indicator		LED green:
		constantly on - power on
		flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode
Function indicator		LED vellow:
Function indicator		constantly on - background detected (object not detected)
		constantly off - object detected
Control elements		Light-on/dark-on changeover switch
Control elements		Sensing range adjuster
lectrical specifications		
Operating voltage	U _B	10 30 V DC
Ripple	OB	max. 10 %
No-load supply current Protection class	I ₀	< 26 mA at 24 V supply voltage
		III.
nterface		
Interface type		IO-Link (via $C/Q = pin 4$)
Device profile		Identification and diagnosis
— ()		Smart Sensor type 2.4
Transfer rate		COM 2 (38.4 kBaud)
IO-Link Revision		1.1
Min. cycle time		2.3 ms
Process data witdh		Process data input 1 Bit
		Process data output 2 Bit
SIO mode support		yes
Device ID		0x111702 (1120002)
Compatible master port type		A
Dutput		
Switching type		The switching type of the sensor is adjustable. The default
		setting is: C/Q - Pin4: NPN normally open / dark-on, PNP normally closed /
		light-on, IO-Link
		/Q - Pin2: NPN normally closed / light-on, PNP normally open /
		dark-on
Signal output		2 push-pull (4 in 1)outputs, short-circuit protected, reverse
		polarity protected, overvoltage protected
Switching voltage		max. 30 V DC
Switching current		max. 100 mA , resistive load
Usage category		DC-12 and DC-13
Voltage drop	Ud	≤ 1.5 V DC
Switching frequency	f	500 Hz
Response time		1 ms
Conformity		
Communication interface		IEC 61131-9
Product standard		EN 60947-5-2
		EN 00347-5-2
Ambient conditions		
Ambient temperature		-40 60 °C (-40 140 °F)
Stavage temperature		
Storage temperature		-40 70 °C (-40 158 °F)
Aechanical specifications		
•		15 mm
Housing width		50.6 mm
•		
Housing width		41.7 mm
Housing width Housing height		41.7 mm IP67 / IP69 / IP69K
Housing width Housing height Housing depth		
Housing width Housing height Housing depth Degree of protection		IP67 / IP69 / IP69K
Housing width Housing height Housing depth Degree of protection Connection Material		IP67 / IP69 / IP69K 4-pin, M12 x 1 connector, 90° rotatable
Housing width Housing height Housing depth Degree of protection Connection		IP67 / IP69 / IP69K

Accessories
IO-Link-Master02-USB IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection
V1-G-2M-PUR Female cordset, M12, 4-pin, PUR cable
V1-W-2M-PUR Female cordset, M12, 4-pin, PUR cable
Other suitable accessories can be found at www.pepperl-fuchs.com

Mass

2

approx. 37 g

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com


Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Approvals and certificates

UL approval CCC approval E87056 , cULus Listed , class 2 power supply , type rating 1 CCC approval / marking not required for products rated ≤36 V

Minimum object height (typical)



To unlock the adjustment functions, rotate the sensing range/sensitivity adjuster by more than 180°.

Sensing Range/Sensitivity

To increase the sensing range/sensitivity, rotate the sensing range/sensitivity adjuster clockwise.

To reduce the sensing range/sensitivity, rotate the sensing range/sensitivity adjuster counter-clockwise.

As soon as the end of the adjustment range is reached, the signal indicator flashes at 8 Hz.

Configuring Light On/Dark On

Press the light-on/dark-on changeover switch for more than 1 second (but less than 4 seconds). "Light on/dark on" mode changes and the relevant operating indicator lights up.

If you press the light-on/dark-on changeover switch for longer than 4 seconds, the "light on/dark on" mode will switch back to the original setting. The current status is activated when the light-on/dark-on changeover switch is released.

Restoring Factory Settings

Press the light-on/dark-on changeover switch for more than 10 seconds (but less than 30 seconds) until all LEDs go out. When the light-on/dark-on changeover switch is released, the signal indicator lights up. After 5 seconds, the sensor resumes operation with the factory settings.

The adjustment functions are locked after 5 minutes of inactivity. To unlock the adjustment functions, rotate the sensing range/ sensitivity adjuster again by more than 180°.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

