









Model Number

OBT80-R103-EP-IO-0,3M-V3-1T-L

Triangulation sensor (BGE) with fixed cable and 3-pin, M8 connector

Features

- Miniature design with versatile mounting options
- Secure and gapless detection, even near the surface through background evaluation
- DuraBeam Laser Sensors durable and employable like an LED
- Extended temperature range -40°C ... 60°C
- High degree of protection IP69K
- IO-link interface for service and process data

Product information


The R103 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design — from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.

Dimensions



Electrical connection




Pinout

Wire colors in accordance with EN 60947-5-2

BN BU

Indicators/operating means



- Light-on/dark-on changeover switch
- Sensing range adjuster
- 3 Operating indicator / dark on
- 4 Function indicator
- Operating indicator / light on

Technical data General specifications Detection range 7 ... 80 mm 7 ... 25 mm Detection range min. Detection range max 7 ... 80 mm Adjustment range 25 ... 80 mm standard white, 100 mm x 100 mm Reference target Light source laser diode Light type modulated visible red light Laser nominal ratings Note LASER LIGHT, DO NOT STARE INTO BEAM Laser class Wave length Beam divergence > 5 mrad d63 < 1 mm in the range of 150 mm ... 250 mm Pulse length 3 us Repetition rate approx. 13 kHz max. pulse energy 10.4 nJ Black/White difference (6 %/90 %) < 5 % at 120 mm Diameter of the light spot < 1 mm at a distance of 60 mm Angle of divergence approx. 0.3 EN 60947-5-2 40000 Lux Ambient light limit Functional safety related parameters $MTTF_d$ 560 a Mission Time (T_M) 20 a 0 % Diagnostic Coverage (DC) Indicators/operating means Operation indicator LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode Function indicator constantly on - object detected constantly off - object not detected Control elements Light-on/dark-on changeover switch Control elements Sensing range adjuster **Electrical specifications** U_{B} Operating voltage 10 ... 30 V DC Ripple max. 10 % No-load supply current I_0 < 20 mA at 24 V supply voltage Protection class Interface IO-Link (via C/Q = pin 4) Interface type Device profile Smart Sensor COM 2 (38.4 kBaud) Transfer rate **IO-Link Revision** 1.1 Min. cycle time 2.3 ms Process data witdh Process data input 1 Bit Process data output 2 Bit SIO mode support Device ID 0x110706 (1115910) Compatible master port type Output Switching type The switching type of the sensor is adjustable. The default C/Q - Pin4: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link 1 push-pull (4 in 1) output, short-circuit protected, reverse Signal output polarity protected, overvoltage protected max. 30 V DC Switching voltage Switching current max. 100 mA, resistive load DC-12 and DC-13 Usage category Voltage drop U_d ≤ 1.5 V DC Switching frequency 1650 Hz 300 us Response time Conformity Communication interface IEC 61131-9 Product standard FN 60947-5-2 Laser safety EN 60825-1:2014 **Ambient conditions** -40 ... 60 °C (-40 ... 140 °F) , fixed cable -25 ... 60 °C (-13 ... 140 °F) , movable cable not appropriate for Ambient temperature conveyor chains Storage temperature -40 ... 70 °C (-40 ... 158 °F) **Mechanical specifications** Housing width 15 mm

Laserlabel



CLASS 1 LASER PRODUCT

IEC 60825-1: 2007 certified. Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007

CLASS 1 LASER PRODUCT

IEC 60825-1: 2007 certified.
Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007

Accessories

IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

V3-WM-2M-PUR

Cable socket, M8, 3-pin, PUR cable

OMH-R103-01

Mounting bracket

V31-GM-2M-PUR

Female cordset, M8, 4-pin, PUR cable

V31-WM-2M-PUR

Female cordset, M8, 4-pin, PUR cable

OMH-R101-Front

Mounting Clamp

OMH-R101

Mounting Clamp

OMH-4.1

Mounting Clamp

OMH-ML6

Mounting bracket

OMH-ML6-U


Mounting bracket

OMH-ML6-Z


Mounting bracket

Other suitable accessories can be found at www.pepperl-fuchs.com

Release date: 2018-06-08 14:41 Date of issue: 2018-06-08 267075-100296_eng.xml



Functions and Operation



- 1 Light-on / dark-on changeover switch
- 2 Sensing range / sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range adjuster / sensitivity adjuster for more than 180 degrees.

Sensing Range/ Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range / sensitivity adjuster for more than 180 degrees.